




TELEDYNE LECROY
Everywhereyoulook™

Summit Z3-16 PCI Express Multi-Lane Exerciser User Manual



PCIe Protocol Suite software version 7.34

Teledyne LeCroy Protocol Solutions Group

Trademarks and Servicemarks

Teledyne LeCroy, *CATC Trace*, *PETracer*, *Summit*, *Summit T3-16*, *Summit T3-8*, *Summit T34*, *Summit T28*, *Summit T24*, *Summit Z3-16*, *Summit T2-16*, *Summit Z2-16*, and *BusEngine* are trademarks of Teledyne LeCroy.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Intel and Pentium are registered trademarks of Intel Corporation.

All other trademarks and registered trademarks are property of their respective owners.


THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL INFORMATION, EXAMPLES AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE REPRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS ARE FULLY RESPONSIBLE FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN INFORMATION THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT TELEDYNE LECROY FOR A COPY.

© 2012 Teledyne LeCroy, Inc. All rights reserved.

This document may be printed and reproduced without additional permission, but all copies should contain this copyright notice.

WEEE Program



Teledyne LeCroy
3385 Scott Blvd.
Santa Clara, CA 95054

TEL: 800-909-7112 (USA and Canada)
TEL: 408-653-1260 (worldwide)

Contents

Chapter 1: Introduction.....	1
1.1 Exerciser Overview.....	1
1.2 Receiving Your Exerciser and the Optional PCI Express Test Platform	2
1.3 Unpacking the Exerciser and the PCI Express Test Platform	2
1.4 Summit Z3-16 Exerciser	2
1.5 Exerciser Features.....	3
1.6 PCI Express Test Platform	3
1.7 PCI Express Test Platform Features.....	4
1.8 Related Reference Documents	6
 Chapter 2: Hardware Description	7
2.1 Exerciser System Components.....	7
2.2 Host Machine Requirements	7
2.3 Summit Z3-16 Exerciser	7
2.3.1 User Interface on the Summit Z3-16 Exerciser	10
2.4 Environmental Conditions.....	10
2.4.1 Connectors.....	10
USB Type B Host Machine Connector	10
Ethernet Port	10
In/Out Connector	10
x16 PCIe Edge Connector	10
2.4.2 LEDs	11
TRAIN (training) LEDs	11
Transmitter and Receiver LEDs	11
2.4.3 Bus LEDs.....	11
2.5 PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s.....	11
2.5.1 Connectors.....	12
AC Power Connector	12

DUT PCIe x16 Connector	12
The Summit Z3-16 Exerciser Power Connector	12
Reference Clock In Connector	13
Reference Clock Out Connector	13
Summit Z3-16 Slot Connector	13
DUT Slot Connector	13
DUT Power Connector	13
Output Connectors	13
To Analyzer (15:8) Connector	13
To Analyzer (7:0) Connector	13
2.5.2 LEDs	13
DUT PRSN LED	13
Power Monitor LED	13
Aux DUT Power LED	14
2.5.3 Switches and Buttons	14
System Power On/Off Switch	14
SSC Switch	14
Reference Clock Switch	14
DUT Power Switch	14
Reset Bus Button	14
2.6 PCI Express Test Platform for Summit™ Z3-16 Exerciser with	
.....CLKREQ# and SRIS Support	14
2.6.1 Connections	16
DUT Under Test	17
DUT Reference Clocks, Summit Z3-16 Clocks, iPass Cable, Power Connection	17
Switches and LEDs	18
Reference Clock for DUT (SRIS), DUT Power Connectors, DUT Switches, DUT LEDs	18
Clock Logic Diagram	19
2.7 PCI Express PXP-100B Test Platform 16x2.5GT/s / 16x5.0GT/s	20
2.7.1 Connections, LEDs and Switches	21
Clock Input Specification	21
Clock Output Specification	21
.....	21
Chapter 3: Installation	23
3.1 Software Installation	23
3.1.1 Installing the PCIe Protocol Suite software	23
3.2 Setting Up the Summit Z3-16 Exerciser using a USB Connection	24
3.3 Setting Up the Summit Z3-16 Exerciser using an Ethernet Connection	25
3.4 Adding Devices Manually	28

3.5 Setting Up the Summit Z3-16 Exerciser.....	30
3.5.1 Connecting the Summit Z3-16 Exerciser Directly to a Host Machine.....	30
3.5.2 Connecting the Summit Z3-16 Exerciser to the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s.....	31
 Chapter 4: Traffic Generation	33
4.1 Theory of Operation	33
4.1.1 Overview.....	33
4.1.2 Starting Point	34
4.2 LTSSM Control.....	34
4.2.1 Link Speed Control.....	35
4.2.2 Link Width Control	35
4.2.3 Link State Control.....	35
4.2.4 LTSSM Arc Tests	36
4.2.5 LTSSM Log.....	36
4.3 Exerciser Control Bar.....	37
4.4 Generating Traffic.....	39
4.5 Script Execution	40
4.6 Creating a Traffic Generation File	41
4.6.1 Exporting a CATC Trace to a Traffic Generation File.....	41
4.6.2 Saving a Script to a New File.....	42
4.6.3 Creating a New Empty Generation File	43
4.7 Generation Options Dialogs Overview	43
4.7.1 Opening the Dialog.....	43
Dialog Layout	44
4.7.2 General	44
4.7.3 Link	46
4.7.4 Phy Parameters	48
4.7.5 Integrity	52
4.7.6 Flow Control.....	55
4.7.7 Transactions Device Emulation	57
4.7.8 Transactions Host Emulation	58
4.7.9 Transactions Fast Memory Completer	60
4.7.10 Transactions: Enable Precision Time Management (PTM).....	63
Enable PTM.....	63
4.7.11 Low Power.....	64
4.8 Generating Traffic: Set Generation Options	66
4.9 Generating Traffic: Prepare Traffic Generation	66
4.10 Generating Traffic: Begin Traffic Generation.....	67
4.11 Editing Generation Files with the Script Editor	69

4.11.1 Script Editor Toolbar	70
4.11.2 Script Edit Window	71
Syntax Highlighting	71
Tooltips	71
Outlining	71
Text Editing Commands	71
Synchronized Scrolling with the CATC Trace Window	72
4.11.3 Command Properties Window	72
4.11.4 Script Editor File Tabs	74
4.11.5 Script Editor Error Log	74
4.11.6 View Options Menu	74
Chapter 5: Macros	77
5.1 Macros	77
5.1.1 Default Macros: Connect and Disconnect	77
5.1.2 Connect Macro	78
5.1.3 Disconnect Macro	78
5.1.4 Adding New Script Macros	78
Using the Generation Macros Dialog	78
Adding Script Files to the GenScriptMacros Directory	80
5.1.5 Modifying Script Macros	80
5.1.6 Changing the Order of Macro Icons on the Status Bar	80
5.1.7 Deleting User-Defined Script Macros	82
5.1.8 Restoring the Default Appearance of the Connect and Disconnect Icons	82
Chapter 6: Configuration Space	83
6.1 Configuration Space Editor	83
6.2 Launching the Configuration Space Editor	83
6.2.1 Configuration Space Files	83
6.2.2 Editing	84
6.2.3 BARs Setup	87
6.3 Configuration Read and Write	88
6.4 Expansion ROM Setup	88
Chapter 7: Address Spaces	91
7.1 Memory/IO Space Editor	91
7.2 Memory Regions for Host Emulation	92
7.3 Using StoreData in Device Mode for Z3 Scripting	92

Chapter 8: Updates and Licensing	97
8.1 Updating the Exerciser.....	97
8.2 License Keys	97
8.3 License Information.....	98
 Appendix A: Configuration Space Decoding	 99
A.1 Mandatory Definitions	99
A.2 Mandatory Module Functions	99
A.2.1 DecodeRegister(offset)	99
A.2.2 GetSize()	100
A.3 Configuration Register Types.....	100
A.4 Primitives	100
A.5 Helper File.....	101
 Appendix B: NVMe Drive Emulation.....	 103
B.1 NVME Drive Emulation in Windows 7	103
B.2 NVME Drive Emulation in Ubuntu Linux 14.10 and Linuxv3.1-rc4	107
B.2.1 Hardware Setup for Test Equipment.....	108
 Appendix C: China Restriction of Hazardous Substances Table	 117
 Appendix D: How to Contact Teledyne LeCroy.....	 119
 Index:.....	 121

Chapter 1

Introduction

The Teledyne LeCroy Summit Z3-16 Exerciser™ is an advanced Gen1/2/3 PCI Express verification system capable of generating traffic up to 16 lanes at 8GT/s rates. It blends sophisticated functionality with practical features to speed the development of PCI Express™ IP cores, bridges, switches, add-in boards, and systems.

This user manual describes the installation and operation of the Summit Z3-16 Exerciser. It includes a description and examples of the application.

It also describes the installation and operation of the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s which can be purchased optionally.

1.1 Exerciser Overview

The Summit Z3-16 is Teledyne LeCroy's fourth generation exerciser (traffic generator), a critical test and verification tool to assist engineers in developing and improving the reliability of their systems. It adds support for PCI Express at the Gen3 data rate of 8 GT/s.

For system testing the Summit Z3 can be used in a device emulation mode, where the Summit Z3 is directly plugged in to a System Under Test. Hence, the setup is quick and easy.

For device testing the Summit Z3 is used in combination with the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s which provides host emulation capabilities for Summit Z3. The PCI Express Test Platform has two slots, one for the Summit Z3-16 Exerciser card and the other for the DUT (Device Under Test). Optionally, for Gen1 and Gen2 host emulation, the Summit Z3 can be used with the passive Teledyne LeCroy PXP-100 backplane.

The Summit Z3-16 builds on the extensive programming and verification test libraries established for Teledyne LeCroy's *PETrainer*™ and Summit Z2-16 PCI Express Exercisers, and provides the user a complete suite of test capability, including the ability to test products to the PCI Express 3.0 specification. When used in combination with the Summit T3-16 Protocol Analyzer, engineers have a complete test and development environment for PCI Express Gen3 related work.

1.2 Receiving Your Exerciser and the Optional PCI Express Test Platform

The Summit Z3-16 Exerciser can be ordered either with or without the PCI Express Test Platform. You can use the Summit Z3-16 Exerciser card directly in a system using the AC adapter to power the card. If you purchased the PCI Express Test Platform, you can use the Summit Z3-16 Exerciser on the PCI Express Test Platform in the provided slot. In this case the PCI Express Test Platform supplies power to the Summit Z3-16 Exerciser.

The Summit Z3-16 Exerciser package includes the following components:

- ☐ Summit Z3-16 Exerciser identified in the packing list
- ☐ Summit Z3-16 Exerciser Quick Start Guide
- ☐ USB A-B 2.0 cable, 1.8 meter
- ☐ Ethernet cable, 10 feet
- ☐ AC Adapter
- ☐ Installation DVD-ROM with software and documentation

The PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s package includes the following components:

- ☐ PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s identified in the packing list
- ☐ Power cable for Summit Z3
- ☐ AUX power cables for DUT
- ☐ AC power cord

1.3 Unpacking the Exerciser and the PCI Express Test Platform

Inspect the received shipping container for any damage. Unpack the container and account for each of the system components listed on the accompanying packing list. Visually inspect each component for absence of damage. In the event of damage, notify the shipper and Teledyne LeCroy Corporation. Retain all shipping materials for shipper's inspection.

1.4 Summit Z3-16 Exerciser

The Teledyne LeCroy Summit Z3-16 Exerciser is a critical PCIe test and verification tool intended to assist engineers in improving the reliability of their systems. It is a Gen3 PCI Express 16-lane advanced Exerciser system that can emulate PCI Express root complexes or device endpoints. You can test PCI Express IP cores, semiconductors, bridges, switches, and systems.

1.5 Exerciser Features

The Exerciser has the following features:

- ❑ Bidirectional x1-x16, 2.5 GTs to 8.0 GTs generation support for accurate generation of PCI Express bus traffic.
- ❑ Host/Device Emulation Support for allowing design and stress testing.
- ❑ Link Training and Status State Machine (LTSSM) Testing to exercise LTSSM state transitions for verification.

The latest Z3 Trainer supports CLKREQ# signal that allows for L1 Substrate testing. The older versions of the Z3 Trainer do not have this capability.




Figure 1.1: Summit Z3-16 Exerciser Front View.

The dimensions of the main board are 16.8 x 13.3cm or 6.6" x 5.25".

1.6 PCI Express Test Platform

The PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s is a convenient, powerful and flexible PCI Express Test Platform for PCI Express devices at data rates up to

8 GT/s and lane widths up to x16. It can be used in conjunction with the Summit Z3-16 to create a DUT environment.

1.7 PCI Express Test Platform Features

The PCI Express Test Platform has the following features:

- ❑ The PCI Express Test Platform accessory to the Summit Z3-16 Exerciser allows testing and debugging of the PCI Express cards by providing host emulation.
- ❑ The PCI Express Test Platform supports PCIe rates up to 8 GT/s.
- ❑ Lane widths of x1, x2, x4, x8 and x16 are supported.
- ❑ Mechanical support and power is provided for both the Summit Z3-16 Exerciser and the device under test (DUT).
- ❑ Flexible Reference Clock options.
 - The PCI Express Test Platform provides a PCIe clock. Clocking with or without SSC (Spread Spectrum Clocking) can be selected. Additionally, an external clock can be provided through a SMA connector.
- ❑ Power ON/OFF for the DUT.
- ❑ DUT power control
 - DUT power can be switched off without powering PCI Express Test Platform off.
- ❑ The latest version of the Test Platform supports SRIS and CLKREQ#. Older versions of the Test platform do not have these capabilities.
- ❑ Review the Quick Start Guide for your product to learn how to properly configure the platform.




Figure 1.2: PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s.

1.8 Related Reference Documents

For additional information refer to the following documents:

1. PCIe Protocol Suite/Trainer Automation Manual
2. PETrainer Scripting Language Reference Manual
3. Quick Start Guides:
 - ❑ Summit Z3-16 PCI Express Exerciser
 - ❑ PCI Express Test Platform 16x2.5GT/s /16x5.0GT/s / 16x8.0GT/s
 - ❑ PCI Express Test Platform for Summit™ Z3-16 Exerciser with CLKREQ# and SRIS Support
 - ❑ Summit Z3-16 PCI Express Exerciser with CLKREQ# support

Chapter 2

Hardware Description

This chapter describes the hardware for the Summit Z3-16 Exerciser and the PCI Express Test Platform.

2.1 Exerciser System Components

The exerciser has the following components:

- ❑ Summit Z3-16™ Exerciser card
- ❑ x16 to x1 Edge Adapter
- ❑ x16 to x4 Edge Adapter
- ❑ x16 to x8 Edge Adapter
- ❑ PCIe Protocol Suite software program DVD-ROM

2.2 Host Machine Requirements

The Summit Z3-16 Exerciser connects to a host machine. Please consult the **readme** file on the installation DVD for the latest host machine requirements.

2.3 Summit Z3-16 Exerciser

The Summit Z3-16 is a multi-lane PCI Express Exerciser (see [Figure 2.3 on page 8](#)) designed to assist engineers in improving reliability of their solutions and providing advanced capabilities for stress and compliance testing.

All models operate as standalone Exercisers capable of generating and responding to all types of PCI Express transactions. Exercisers also have the ability to create protocol variations and anomalies. Users may create corner case and stress test scenarios to evaluate the robustness of their solutions. By utilizing the error injection feature, engineers can create worst-case PCI Express traffic scenarios allowing them to validate the error handling capabilities of their solutions.

When used in conjunction with an Analyzer, such as the Teledyne LeCroy Summit T3-16, a complete expert test and analysis system is created. This integrated solution delivers traffic generation and protocol analysis to assist developers with early validation of designs compliance test preparation with error injection and stress testing.

Device Emulation is a standard feature and host emulation is available through the optional PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s.

WARNING: There are no user serviceable parts. For servicing please contact Customer Support at Teledyne LeCroy.




Figure 2.3 Summit Z3-16 Exerciser Front View.




Figure 2.4 Summit Z3-16 Exerciser Rear View Showing the UI with LEDs.

The Summit Z3-16 is a stand-alone PCI Express Exerciser that can control LTSSM, the Data Link Layer and the Transaction Link Layer to send and receive packets to transfer the data.

The Summit Z3-16 can establish the link from x1 through x16 lane system and change speed from Gen1, Gen2 and Gen3 to exercise LTSSM State Transitions for verification.

2.3.1 User Interface on the Summit Z3-16 Exerciser

The Summit Z3-16 bracket contains the following interface components:

- ☐ Power On/Off LED
- ☐ Power socket for the 12V DC Power Connector
- ☐ Power requirement is 100-240 VAC, 47-63 Hz universal input for AC Adapter which is included
- ☐ USB Type B Host Machine Connector
- ☐ Ethernet port

2.4 Environmental Conditions

The environmental condition specifications are:

- ☐ Operating range from 0 to 40°C (32 to 104°F), 0 to 90% humidity, non-condensing
- ☐ Storage range from -10 to 80°C (-4 to 176°F)

WARNING: Since the electrical components on the Summit Z3-16 card are exposed, please use standard ESD practices when handling the board; otherwise, it could be damaged.

2.4.1 Connectors

USB Type B Host Machine Connector

This connector links the Summit Z3-16 Exerciser to the host machine for the purpose of downloading generation scripts and controlling the behavior of the Exerciser.

Note: Use either USB or Ethernet, not both.

Ethernet Port

A 10/100/1000baseT Ethernet connector to the host machine is provided. GIGE Connectivity allows connection to an Ethernet network. This connector links an Exerciser to the host machine for the purpose of downloading generation scripts and controlling the behavior of the Exerciser.

Note: Use either USB or Ethernet, not both.

In/Out Connector

This is for future use.

x16 PCIe Edge Connector

The x16 PCIe Edge connector can be adapted to x8, x4 or x1 slots through the use of a Card Reducer Edge Adapter.

2.4.2 LEDs

When powered on, the Summit Z3-16 Exerciser activates user accessible LEDs on the back of the card.

TRAIN (training) LEDs

There is a TRAIN LED indicating whether the link is TRAINED or not.

Transmitter and Receiver LEDs

There are 32 LEDs, 16 for Transmitting and 16 for Receiving. These LEDs light up in two colors displaying transmitting or receiving activity.

- ☐ Green - no errors on the lane
- ☐ Yellow - the Summit Z3-16 Exerciser detects errors on this lane

2.4.3 Bus LEDs

There are 3 LEDs indicating the operating speed of 2.5/5.0/8.0 GT/s which is Gen1, Gen2 and Gen3 bus speed.

2.5 PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s

The PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s (see [Figure 2.5 on page 12](#)) for the Summit Z3-16 Protocol Exerciser can be purchased optionally to allow the Summit Z3-16 Exerciser to act as a host machine, enabling extensive protocol level testing of PCIe devices. It provides a convenient, powerful and flexible PCI Express Test Platform for PCI Express devices at data rates up to 8 GT/s and lane widths up to x16. It has two PCIe slots, one dedicated to the Summit Z3-16 Exerciser and another for the Device Under Test. The Summit Z3-16 Exerciser can be conveniently powered by the PCI Express Test Platform using a special power cable, which eliminates the need for an AC power adapter. When purchased with the Summit Z3-16 Exerciser it provides power to the Summit Z3-16 Exerciser. The PCI Express Test Platform has a DUT PCIe x16 slot to capture protocol traffic between systems.

In addition, there is a complete Gen3 protocol analyzer interposer built into the platform to enable connectivity with a PCIe analyzer such as the Summit T3 to monitor exerciser traffic.

When the PCI Express Test Platform is powered on it provides power to the DUT slot and the Summit Z3 slot. When using the PCI Express Test Platform you can choose a generic internal reference clock or external reference clocking from an external source.




Figure 2.5 PCI Express Test Platform Front and Side View.

2.5.1 Connectors

AC Power Connector

The AC Power Connector operates at 100-240V, 50-60 Hz, 500W.

DUT PCIe x16 Connector

This slot supplies 3.3V up to 3A and 12V up 5.5A.

The Summit Z3-16 Exerciser Power Connector

A 2-Pin DC Power Connector for the Summit Z3-16 is provided.

Reference Clock In Connector

This connects the external reference clock source that can be selected by an external clock selection switch. The clock will be delivered to both PCIe slots.

Reference Clock Out Connector

This provides external reference clock output.

Summit Z3-16 Slot Connector

This is designed to be used with the Summit Z3-16 Exerciser. It can also be used with other equipment and is powered via the PCI Express Test Platform.

DUT Slot Connector

This connector is designed to be used with the DUT. Power to this slot is controlled by the DUT Power switch. When the DUT power switch is off all the DUT power is off including auxiliary power.

DUT Power Connector

DUT 6-Pin DC Power Connector which supplies 12 Volts up to 6.25 Amps for cards needing more power, such as a graphic card. Cables are provided for this connector.

DUT 8-Pin DC Power Connector which supplies 12 Volts up to 12.5 Amps for cards needing more power, such as a graphic card. Cables are provided for this connector.

Output Connectors

Two output iPass Connectors are provided for use with a Protocol Analyzer.

To Analyzer (15:8) Connector

Connects to Summit T3-16 Analyzer (lanes 15:8). This is an optional connection for users adding a Summit T3-16 Analyzer to their setup.

To Analyzer (7:0) Connector

Connects to Summit T3-16 Analyzer (lanes 7:0). This is an optional connection for users adding a Summit T3-16 Analyzer to their setup.

2.5.2 LEDs

When powered on, the PCI Express Test Platform powers the Summit Z3-16 Exerciser and activates user accessible controls and LEDs on the back of the card.

DUT PRSN LED

There are four DUT PRSN LEDs that show the state of the DUT x1, x4, x8 and x16 present signals.

Power Monitor LED

There are two LEDs to monitor power to the lower PCIe slot indicating 3.3V or 12V.

Aux DUT Power LED

There are two LEDs to monitor the auxiliary power to the DUT indicating 3.3V or 12V.

2.5.3 Switches and Buttons

System Power On/Off Switch

This switch is used to power the PCI Express Test Platform on and off.

SSC Switch

This switch is used to turn Spread Spectrum Clocking on and off only when using the internal reference clock. When using an external reference clock, this switch has no effect.

Reference Clock Switch

The Reference Clock Selector switch is used to select the internal or external clock on the PCI Express Test Platform. The PCI Express Test Platform is capable of taking an external reference clock source, or it can generate its own clock. The clock is delivered to both PCIe slots.

DUT Power Switch

This switches the DUT power, both auxiliary and slot power, on and off.

Reset Bus Button

There is a Reset Bus button provided on the platform to emulate the PE Reset.

2.6 PCI Express Test Platform for Summit™ Z3-16 Exerciser with CLKREQ# and SRIS Support

Teledyne LeCroy's PCI Express 3.0 Test Platform for the Summit Z3-16 Protocol Exerciser provides a convenient, powerful and flexible test platform for PCI Express devices at data rates up to 8 GT/s and lane widths up to x16.

The Test Platform allows the Summit Z3-16 Exerciser to act as a host system, enabling extensive protocol-level testing of PCIe® devices. In addition, there is a complete Gen3 protocol analyzer interposer built into the platform complete with iPass connectors for up to x16 lane support.

For use as a host emulator, the Summit Z3-16 Exerciser is plugged into the dedicated PCIe slot and connected to the power source provided by the Test Platform. The DUT is plugged into the PCIe x16 slot, and connected to either the 6-pin or the 8-pin 12V power sources provided on the Test Platform.

Switches on the platform allow the user to select internal or external reference clocks separately for the Summit Z3-16 and DUT, SSC, SRIS, CLKREQ# and power for the DUT. Connectors on the platform include two PCIe x16 slots, dual Ref Clock IN and OUT, dual iPass connectors for connection to a Teledyne LeCroy protocol analyzer such as the

Summit T3-16, and DC power connectors (2-pin for the Summit Z3-16, and the choice of 6-pin or 8-pin for the DUT).

In addition to using the Test Platform with the Teledyne LeCroy Summit Z3-16, the user can connect two of their own devices and use the Test Platform as a PCIe backplane and as an interposer to capture protocol traffic between the systems. See [Figure 2.6](#).



Figure 2.6 PCIe Test Platform Supporting Summit Z3-16 with SRIS and CLKREQ#

2.6.1 Connections

Connections to the PCIe Test Platform Supporting the Summit Z3-16 Exerciser with SRIS and CLKREQ# can be seen in [Figure 2.7](#).




Figure 2.7 Connections to PCIe Test Platform Supporting Summit Z3-16 Exerciser with CLKREQ# and SRIS

DUT Under Test

- ❑ **DUT PCIe x16 Connector:** Supplies 3.3 V up to 3 A and 12 V up to 5.5 A.


**DUT (Device Under Test)**

Figure 2.8 Device Under Test Connector

DUT Reference Clocks, Summit Z3-16 Clocks, iPass Cable, Power Connection

- ❑ **DUT Reference Clock Out Connector:** Provides a copy of the clock currently supplied to the DUT slot.
- ❑ **DUT Reference Clock In Connector:** Connects external reference clock source for the DUT. Clock is delivered to the DUT slot depending on switch configuration, see switch selection tables and diagram. To drive the 100 MHz clock input the following sources can be used: CML, HCSSL, LVPECL and LVDS. If your clock source is differential, connect the unused differential output to the appropriate loading resistor.
- ❑ **iPass Connectors:** 2 output iPass connectors for use with Protocol Analyzer (such as Summit T3-16)
- ❑ **Summit Z3-16 Power Connector:** 2-pin DC power connector to provide power for Summit Z3-16 (supplies 12v up to 6.25A)
- ❑ **Summit Z3-16 Reference Clock Out Connector:** Provides a copy of the clock currently supplied to the Summit Z3 slot
- ❑ **Summit Z3-16 Reference Clock In Connector:** Connects external reference clock source for the Summit Z3-16. Clock is delivered to the Summit Z3-16 slot depending on switch configuration. See switch selection tables and diagram. To drive the 100 MHz clock input the following sources can be used: CML, HCSSL, LVPECL and LVDS. If your clock source is differential, connect the unused differential output to the appropriate loading resistor.




Figure 2.9 Clock, Power and Data Connectors

Switches and LEDs

- ❑ **Reset Bus Button:** Generates PERST# reset.
- ❑ **DUT PRSNT LEDs:** 4 LEDs indicate whether x1, x4, x8, or x16 DUT is plugged in.
- ❑ **CLKREQ Selector Switch:** Allows for CLKREQ# to turn off the clocks when enabled.
- ❑ **Summit Z3-16 PCIe x16 Slot:** Powered by Test Platform, supplies 3.3V up to 3A and 12V up to 5.5A. Can be used with other equipment.
- ❑ **SSC Selector Switch (for Z3-16):** When using the internal reference clock, turns Spread Spectrum Clocking (SSC) on or off. If using external reference clock, the switch has no effect.
- ❑ **Z3-16 Reference Clock Selector Switch:** Selects the internal or external clock. Clock is delivered to Summit Z3 slot.
- ❑ **Z3-16 Slot Power Monitor LEDs:** 2 LEDs monitor power to Summit Z3 slot.




Figure 2.10 Switches and LEDs

Reference Clock for DUT (SRIS), DUT Power Connectors, DUT Switches, DUT LEDs

- ❑ **SRIS Control Switch for DUT:** Select Common (both slots use the same clock) or Separate (each slot uses an independent clock).
- ❑ **SSC Selector Switch (for DUT):** When using the internal reference clock, turns Spread Spectrum Clocking (SSC) on or off. If using external reference clock, the switch has no effect.
- ❑ **DUT Reference Clock Selector Switch:** Selects the internal or external clock. Clock is delivered to DUT slot.
- ❑ **DUT Power Selector Switch:** The DUT Power switch controls power to the DUT slot.
- ❑ **DUT Power Monitor LEDs:** 2 LEDs monitor power to the DUT: 3.3 V or 12 V.
- ❑ **DUT 6-pin DC Power Connector:** Supplies 12 V up to 6.25 A for graphics cards (cable provided).
- ❑ **DUT 8-pin DC Power Connector:** Supplies 12 V up to 12.5 A for graphics cards (cable provided).




Figure 2.11 Aux DUT Power Connectors, LEDs, Clock Switches

Clock Logic Diagram

- ❑ **Clock Logic Diagram:** For selecting reference clocks including SSC and SRIS.




Figure 2.12 Clock Logic Diagram

2.7 PCI Express PXP-100B Test Platform 16x2.5GT/s / 16x5.0GT/s

Teledyne LeCroy's PCI Express PXP-100B Test Platform 16x2.5GT/s / 16x5.0GT/s provides a convenient, powerful and flexible test platform for PCI Express devices at data rates up to 5 GT/s and lane widths up to x16.

The Test Platform allows the Summit Z3-16 Exerciser to act as a host system, enabling extensive protocol-level testing of PCIe[®] devices.

For use as a host emulator, the Summit Z3-16 Exerciser is plugged into any slot and connected to an external power source. The DUT is plugged into the remaining available slot, the PXP-100B provides the necessary power up to 75W per slot.

In addition to using the Test Platform with the Teledyne LeCroy Summit Z3-16, the user can connect two of their own devices and use the Test Platform as a PCIe backplane by adding an interposer or using the built in midbus footprint and using a midbus probe will allow an analyzer to capture protocol traffic between the devices. See [Figure 2.13](#).



Figure 2.13 PXP-100B PCI Express Test Platform

2.7.1 Connections, LEDs and Switches

Connections, LEDs and Switches to the PCI Express PXP-100B Test Platform can be seen in [Figure 2.14](#).




Figure 2.14 PCI Express PXP-100B Test Platform Top View

Clock Input Specification

Parameter	Specification
Peak to peak voltage level	0.3 V (Min), 1 V (Max)
Input interface level accepted	LVPECL, LVDS, LVHSTL, SSTL, HCSL
Nominal frequency	100 MHz

Clock Configuration

J1000	Selected Clock
Short	External
Open	Internal

Clock Output Specification

Parameter	Specification
Peak to peak voltage level	0.3 V
Interface level	LVDS
Nominal frequency	100 MHz

Chapter 3

Installation

This chapter provides instructions to install the Summit Z3-16 Exerciser, the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s and software installation.

3.1 Software Installation

This section describes the PCIe Protocol Suite installation on your host machine. The PCIe Protocol Suite operates on systems using the Windows 8 (x86 and x64), Windows Server 2012 (x64), Windows 7 (x86 and x64), Windows Server 2008R2 (x64), Windows XP (x86). The latest Service Pack available for the Windows OS in use is required. It is recommended that you use one of the supported 64-bit Windows versions listed above as they allow using more RAM than the 32-bit ones.

Once you have installed the software, you can begin traffic generation after following the steps in this chapter.

3.1.1 Installing the PCIe Protocol Suite software

PCIe Protocol Suite software operates all of Teledyne LeCroy's PCI Express protocol Analyzer and Exerciser products:

The PCIe Protocol Suite software is installed on a Microsoft® Windows®-based host machine and serves as the interface for the Exerciser and/or Analyzer.

To install the Protocol Software Suite on the host machine:

1. Insert the Installation DVD-ROM into the DVD drive on the host machine.
2. The installation automatically starts setup, unless Auto Run is off. In that case, select the DVD-ROM from "My Computer" and click **Setup**.
3. After the warning to close all other programs and before starting the installation, the Install component selection opens.
4. Select components for installation.
5. Click **Next** to complete the installation.
6. To start the application, launch the PCIe Protocol Suite program from the Start menu:

Start > Programs > LeCroy > PCIe Protocol Suite > PCIe Protocol Suite

Note: You can also download the software from the Teledyne LeCroy website and install it following steps 2 through 6 above.

The PCIe Protocol Suite program opens.




Figure 3.15: Teledyne LeCroy PCIe Protocol Suite

Note: The software may be used with or without the Exerciser or Analyzer. When used without an Exerciser or Analyzer attached to the computer, the program functions as a CATC Trace Viewer to view and analyze captured traffic.

3.2 Setting Up the Summit Z3-16 Exerciser using a USB Connection

To set up the Exerciser using a USB connection:

1. Connect the Exerciser to a 100-volt to 240-volt, 50 Hz to 60 Hz, 120 W power outlet using the provided power cord.
2. Connect the USB port to a USB port on the host machine using a USB cable.

Note: To connect using Ethernet, see [“Setting Up the Summit Z3-16 Exerciser using an Ethernet Connection” on page 25](#).

3. Turn on the front power switch.

Note: At power-on, the Exerciser initializes itself in approximately five seconds and performs an exhaustive self-diagnostic that lasts about forty seconds. The results are reflected by messages on the Summit T3-16 LCD display. If the LCD display indicates failure, call Teledyne LeCroy Customer Support for assistance.

4. Follow the Microsoft® Windows® on-screen Plug-and-Play instructions for the automatic installation of the Exerciser as a USB device on your analyzing host machine. (The required USB drivers are installed on your system by the PCIe Protocol Suite application software installation.)

Click **Finish** when you see the message that says “Windows has finished installing the software that your new hardware requires” and the file has been installed in your host machine.

3.3 Setting Up the Summit Z3-16 Exerciser using an Ethernet Connection

1. Connect the Exerciser to a 100-volt to 240-volt, 50 Hz to 60 Hz, 120 W power outlet using the provided power cord.
2. Connect the Summit Z3 Exerciser to the network.

Note: To connect using USB, see [“Setting Up the Summit Z3-16 Exerciser using a USB Connection” on page 24](#).

3. Turn on the front power switch.

Note: At power-on, the Exerciser initializes itself in approximately five seconds and performs an exhaustive self-diagnostic that lasts about forty seconds.

4. After you have installed the PCIe Protocol Suite application software, perform the following procedure to connect to a Summit Z3-16 Exerciser in the local network. Select the **Setup > All connected devices...** menu in the PCIe Protocol Suite application software to display the Exerciser Devices dialog.




Figure 3.16: Exerciser Devices Dialog

The PCIe Protocol Suite application software fills the list with devices that are connected over USB or discovered on the Ethernet network. The discovery mechanism works only within one network subnet. If a Summit Z3 is connected to the network on a different subnet, you can manually add the subnet to the list by clicking the **Add Device** button and specifying the IP address.

The Summit Z3 devices in the list are marked:

- ☐ **Locked:** Some other client on the network is already connected to that device
 - ☐ **Ready to connect:** Available for connection
1. If a Summit Z3 device is marked Ready To Connect, you can select that device and press the **Connect** button to execute the connection procedure.
After the connection is established, the application displays the Connection Properties dialog.




Figure 3.17: Connection Properties Dialog

2. Select an option:

- ❑ **Automatically connect to the device:** When the application is started or when the named device is added to the network while the PCIe Protocol Suite application is running on this computer, the software will try to connect to the named device.
- ❑ **Ask if I want to connect to the device:** When the application is started or when the named device is added to the network while the PCIe Protocol Suite application is running on this computer, the software will display a message box allowing you to connect to the named device.
- ❑ **Take no action:** When you start the application or when you want to add the named device to the network while the PCIe Protocol Suite application is running on this computer, you must connect manually to use the named device.

Note: When you close the application on this computer (or you perform a manual disconnect), the application disconnects from the device.

3. Press **OK** in the Connection Properties dialog.

After you finish the connect procedure, the Summit Z3 device to which you have connected is marked as **Ready** and you can use it for recording (see [Figure 3.18 on page 28](#)).




Figure 3.18: Analyzer Devices Dialog Showing all Connected Devices

Note: To disconnect from a device, display this dialog, select the device, and click the **Disconnect** button.

Note: As of version PCIe Protocol Suite version 7.34, the software is able to access a Summit exerciser via VPN solutions that require explicit bindings to PPP adapters that they create.

3.4 Adding Devices Manually

You can locate and add a Summit Z3 located in a Ethernet subnet using the Add Device button. Perform the following steps:

Click **Setup -> All Connected Devices -> Add Device ->** to display the Add Ethernet Attached Device dialog.




Figure 3.19: Add Ethernet Attached Devices Dialog

Click the **Recent** button to display a list of recently added devices (up to 15) and quickly add a recently used device.

Click the **Ping** button to ping a device as a network node (prompting an error message if no response). Ping also allows PCIe Protocol Suite application to detect a device type before actually connecting to the device.

If the "Ping" feature discovers that the device is already connected and "locked" then it will inform the user and provide information about who locked the device.

Click **Setup -> All Connected Devices** to display the Exerciser Devices dialog .

If the software fails to connect to a manually added device, a message displays notifying the user about the connection failure. The user is given the option to keep the failed device in the device list, in this case the PCIe Protocol Suite application displays a "Failed to connect" status message in grey.

Square brackets for IP addresses are used for manually added devices to easily distinguish them from auto-discovered devices.




Figure 3.20: Add Ethernet Attached Devices Dialog

3.5 Setting Up the Summit Z3-16 Exerciser

The Summit Z3-16 Exerciser can test both the host and device sides of a PCI Express link through the use of two types of adapters:

- ❑ **Motherboards and host controllers:** When using the Summit Z3-16 Exerciser as a device emulator, the Summit Z3-16 Exerciser is an adapter card that fits into motherboards and other slotted PCI Express devices.
- ❑ **PCI Express add-on cards: Using a Summit Z3-16 PCI Express Multi-Lane Exerciser User Manual.** A PCI Express Test Platform is a box-like adapter with a slot for testing PCI Express cards.

Both of these test devices can be purchased from Teledyne LeCroy.

There are two ways the Summit Z3-16 Exerciser can be connected:

- ❑ Directly inserted into a slot in the host machine
- ❑ Connected via the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s

3.5.1 Connecting the Summit Z3-16 Exerciser Directly to a Host Machine

The Summit Z3-16 Exerciser is inserted into a slot in the host machine.

Connect the AC adapter to the Exerciser. The Summit Z3-16 Exerciser powers on. Do not turn the host machine on till the Exerciser initializes which could take a few minutes.

3.5.2 Connecting the Summit Z3-16 Exerciser to the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s

The PCI Express Test Platform allows the Summit Z3-16 Exerciser to act as a host emulation system. The PCI Express Test Platform enclosure has two slots on top to accommodate the Summit Z3-16 Exerciser and a DUT (Device Under Test).




Figure 3.21: Connecting the Summit Z3-16 Exerciser via the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s.

Hardware enclosure with a slot on top for accommodating a PCI Express card.

TX/RX 8-15 Connector

Connects to Summit T3-16 Exerciser (lanes 15:8). This is an optional connection for users adding a Summit T3-16 Exerciser to their setup.

TX/RX 0-7 Connector

Connects to Summit T3-16 Exerciser (lanes 7:0). This is an optional connection for users adding a Summit T3-16 Exerciser to their setup.

Reset button

Reset asserts PERST# for > 250 ms.

Clock Select

Selects from the following clocking options:

- ❑ **Ext:** a user supplied reference via the **RefCLK** SMA connector.
- ❑ **Int:** an internal supplied 100MHz reference clock.
- ❑ **Int SSC:** an internal supplied 100MHz Spread Spectrum Clock.

Power Select switch

When the DUT Power is turned on 3.3V and 12V is supplied to the DUT slot along with AUX power. Additional Auxiliary Power can be used by connecting to the 6-pin (75W) or 8-pin (150W) connectors.

Power LED

Lights when the PCI Express Test Platform is powered on.

Perform the following steps to connect the Exerciser to the PCI Express Test Platform:

1. Insert the Summit Z3-16 Exerciser card in the Summit Z3 slot on the PCI Express Test Platform.
2. Connect the 12V DC power cable from the PCI Express Test Platform (labeled Z3 Power Cable) to the Summit Z3-16 Exerciser.
3. Insert a DUT in the DUT slot. Connect AUX power if necessary.
4. Select correct reference clock source using clock selection switches.
5. Connect Summit T3 analyzer to Analyzer connectors to monitor traffic between Summit Z3 and DUT (optional).
6. Connect the AC power cable to the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s. Turn the PCI Express Test Platform 16x2.5GT/s / 16x5.0GT/s / 16x8.0GT/s switch on to power the enclosure. The Exerciser's green power LED lights turns on for approximately one minute while the Exerciser performs self-diagnostics.
7. Using the Ethernet or USB cables connect the Summit Z3-16 Exerciser card to the host machine.
8. Open the PCIe Protocol Suite application on the host machine. The Exerciser is now ready for traffic generation.

Traffic Generation

A traffic generator can emulate PCI Express™ root complexes and endpoint devices. Traffic generation can be used to transmit known errors, allowing you to observe how your device handles faulty link conditions.

After the Summit Z3-16 Exerciser and DUT have been cabled and powered on, you can test the setup by generating some traffic. The following steps show how to configure the Exerciser to generate a Link Training sequence.

4.1 Theory of Operation

4.1.1 Overview

The Exerciser offers two mechanisms for implementing traffic generation: scripts, in which any type of traffic can be defined and executed, and the Generation Options dialog box, which offers a collection of PCI Express specific **behaviors** that can be enabled for automatic generation of traffic.

Using scripts, packets can be transmitted consecutively, with specific timing, or with event-based pauses between them. This allows the Exerciser to act as a pattern generator with PCI Express-specific formatting and transmission rates. However, creating traffic that emulates real devices with relatively complex protocol behaviors using a simple pattern generator is quite complicated. Certain behaviors such as ACK policies, and flow control require concurrent processing. This is where the automated features become useful.


The Exerciser includes a collection of automated traffic generation circuits that commonly exist in other PCI Express devices. These circuits include ACK/NAK generation, flow control management, a LTSSM, replay buffers, and transaction timers. What makes the Exerciser unique and so useful is that each of these behaviors can be individually modified or disabled. This allows the user to perform operations that might not otherwise be possible using an off the shelf PCI Express device. This can be particularly useful when doing compliance or fault recovery testing.

4.1.2 Starting Point

When the Exerciser first powers up, it is at electrical idle on all lanes. The link is not trained, but the LTSSM is enabled and waiting for a command to train the link. To begin communication with a PCI Express device, Link training must occur, but first the generation settings must be set. This involves setting the Link parameters such as link width, polarity inversion, and lane reversal, through the Generation Options dialog.

Note: Setting the options in the Generation Options dialog has no effect on the Exerciser behavior until the first script is executed. In fact, each time a script is executed, these behaviors are reprogrammed to the Exerciser and the behaviors are modified accordingly.

4.2 LTSSM Control

The **LTSSM Control** button on the Summit Z3 Exerciser status toolbar  can be pressed to open the LTSSM Control dialog. In this dialog, you can initiate speed switches, initiate link width changes, initiate select link state changes, and run tests on the different arcs of the LTSSM.




Figure 4.1: LTSSM Control Menu.

**Disable Log
Button**

4.2.1 Link Speed Control

The Summit Z3-16 Exerciser supports traffic generation at three speeds: 2.5, 5.0 and 8.0 GT/s. The link speed control shows the current link speed and has buttons to initiate speed switches to corresponding speeds.

When you press a speed control button, the Summit Z3-16 Exerciser initiates a speed switch for the speed indicated on that button. The link may not change speed if the speed switch operation is unsuccessful.

The speed switch buttons may be enabled/disabled based on the speed configuration settings in the exerciser's Generation Options settings. For example, if you set up a Summit Z3-16 Exerciser as a Gen2 capable device in the Generation Options, the Gen3 (8.0GT/s) speed switch button will be disabled.

4.2.2 Link Width Control

The Summit Z3-16 Exerciser supports traffic generation at five different link widths: x1, x2, x4, x8 and x16. The link width control shows the current link width and has buttons to initiate link width changes to corresponding widths.

When you press a link width control button, the Summit Z3-16 Exerciser will initiate a link width change for the link width indicated on that button. The link width after the operation may not match the desired link width if the operation is unsuccessful.

The link width buttons may be enabled/disabled based on the link width configuration settings in the exerciser's Generation Options settings. For example, if you set up the Summit Z3-16 as a x4 device in the Generation Options, the x8 and x16 link width change buttons are disabled.

4.2.3 Link State Control

The Summit Z3 Exerciser currently supports direction to the following nine link states: Detect, Recovery, Hot Reset, Disabled, L0, L0S, Loopback (Compliance Rx=0), Loopback (Compliance Rx=1), Clear Loopback, Direct to L1 (Device Emulation mode only) and Direct to L2 (Device Emulation mode only). The link state control shows the current state of the PCI Express Link. For example, when the Link is down, it shows Detect.

You can direct the Summit Z3-16 into one of the stated nine specific LTSSM states by selecting the desired state in the "Go to Link State" drop down box and pressing the Apply button. The exerciser will then receive instructions to transition into the selected state. The resulting link state after such a transition may be different than the selected state based on the link. For example, if you direct the Summit Z3-16 LTSSM into a Recovery state when the link is at L0, the Summit Z3-16 will initiate a recovery sequence, but after the recovery the link should get back to the L0 state.

The intermediate link states, such as Polling and Configuration, are handled by the Summit Z3-16 exerciser. After receiving a link transition command to L0 / connect, the LTSSM is alive, the exerciser will keep the Link active just as any other PCI Express device would, this includes handling of the Recovery states and subsequent retraining events.

When the Summit Z3-16 is directed to any of the low power states, it should be brought out to L0 first before directing it to another low power state. For example, If the Summit Z3 is in L1, it can not be directed to L0s immediately, you need to first direct it to L0 and from there to L0s.

Note: If the device under test (DUT) does not support Loopback mode, the Summit Z3 may not correctly transition out of Loopback state and a Link Reset may be required.

4.2.4 LTSSM Arc Tests

The Summit Z3-16 Exerciser has been developed to allow for testing of the different arcs of the LTSSM. This list of tests is displayed in the LTSSM Arc Tests in the left pane. When you select a test from the test list, its information is displayed in the adjacent right panel. The information is in the form as follows:

Test: The name of the test.

Test Description: A brief description of the test.

PreRequisites: The expected state that this test is starting from.

Test Scenario: Explains the details of what the test will perform.

Expected DUT State Transitions: The LTSSM states that the Device Under Test is going through.

These tests have different prerequisites that need to be met in order to be run. Tests that have their prerequisites met and that are ready to be run are displayed in black. Tests that do not have their prerequisites met will be grayed out in the list of tests and you will not be able to run them if you select them. In order to run tests that do not have their prerequisites met, you can view the prerequisites and/or the description of the test by clicking on that specific test. From there, you can manipulate the link speed/width/state of the exerciser to match the prerequisites so that the test is enabled to run.

For example, as shown in the LTSSM Control Dialog, the Summit Z3-16 is linked up at 2.5GT/s (Gen1) so the first test is ready to be run but the second and third tests are grayed out since they require 5.0GT/s (Gen2) and 8.0GT/s (Gen3) speeds.

To run a test, select the test and click **Run**. The LTSSM state transitions from the test will be displayed in the LTSSM Log (the bottom pane).

4.2.5 LTSSM Log

After issuing a speed change, link width change, link state transition, and/or running any LTSSM arc test, the LTSSM state transitions that occurred will be displayed in the LTSSM Log. This log will accumulate the state transitions from different run tests and the results from commands issued from the controls. You can clear this log by clicking the Clear Log button and you can also save the log as a text file for future reference by clicking on the Save Log button. Clicking the Save Log button will prompt open the save file dialog. Clicking on the Disable Log button will turn off the logging of data.

Running an LTSSM arc test will clear the logged transitions in the Summit Z3-16 before the test runs to ensure that all the test transitions are recorded. Clearing the log will also clear any logged transitions in the Summit Z3-16.

Note: Reading the entire log takes time and may be unnecessary in some cases. Disable Log option will prevent the application from reading the trainer log.

4.3 Exerciser Control Bar




Figure 4.2: Exerciser Control Bar.

The following icons are displayed in the Exerciser Control Bar.



The **Start Traffic Generation** button starts traffic generation of a currently loaded generation script. Before starting the generation it saves all the changes to the script file. If you start a new script that does not yet have a name, the Save As dialog opens to save the .peg file ([see “Generating Traffic: Begin Traffic Generation” on page 67](#)).



The **Stop Traffic Generation** button stops generation script execution.




The **Resume Traffic Generation** button resumes generation script execution if it was stopped.



Connect and **Disconnect** buttons. When you click the **Connect** button it executes a connect script. It directs the Summit Z3-16 LTSSM into L0 state. It uses the device parameters, such as supported speed and link width, from the Generation Options

Click on the **Disconnect** button to disconnect. It directs the Summit Z3-16 into Detect state.



You can switch to a different speed by clicking on the **Go to 2.5, 5.0, 8.0** buttons. Pressing these buttons will initiate a speed switch. The link may not change speed if the speed switch operation is unsuccessful.



The **Write** and **Read Address Space** buttons. The Summit Z3-16 is capable of emulating device memory spaces. Using these buttons you can load data into the different memory spaces and read data from each of the memory spaces. You can also access these by clicking **Generate > Write Address Space** and **Generate > Read Address Space**. See [Figure 4.3 on page 38](#) and [Figure 4.4 on page 38](#).



Figure 4.3: Write Address Space.




Figure 4.4: Read Address Space.



The **LTSSM control** button brings up another dialog box that allows more options for real time control of the Z3 Trainer.

The following icon may be displayed in the Top tool bar and can also be located in the **Setup** menu option (see figure below).



The **Setup Generation Options** button enables you to configure the generation options (see “[Generation Options Dialogs Overview](#)” on page 43).




Figure 4.5: Top Tool Bar.

4.4 Generating Traffic

To generate traffic, open or create a traffic generation file (*.peg) and then run it.




Figure 4.6: Open Trace File.

When the file is opened, it appears in the CATC Trace window looking like a CATC Trace file.

To run the file, click the **Start Generating Traffic**  button.

To create or edit a **.peg** file, use the Script Editor.





Figure 4.7: Script Editor.

The Script Editor is a text-editing tool that can be opened by clicking  or selecting **File>New** from the menu bar.

Alternatively, the traffic generation file can be created by exporting the data from a CATC Trace into a traffic generator file.

4.5 Script Execution

As mentioned above, each time a script is executed, the configuration settings for the Summit Z3-16 Exerciser are reprogrammed. When the **Start generation** button is pressed, the script is uploaded to the Exerciser hardware and executed immediately. The progress of the script can be tracked in the Exerciser Control Bar at the bottom of the screen. Subsequent executions of the same script do not require upload of the script to the Summit Z3-16 Exerciser, however, as mentioned above, the generation options are still reprogrammed.

Script execution can be throttled using **Wait** commands inserted directly into the script. Waits can be time based, require receipt of certain packet types, or can even require **User** input from the GUI.

After the script is complete, any enabled PCI Express **behaviors**, such as SKIP insertion, Flow control, and ACK generation, continue. This allows you to run multiple scripts, one after another, without interrupting the Link state.

4.6 Creating a Traffic Generation File

There are four ways to create a traffic generation script file:

- ☐ **Export an existing trace** to a script file
- ☐ **Save an existing script** to a new file
- ☐ **Select File > New** to create a new and empty script file that contains no text.
- ☐ **Create an empty file** using an OS shell (with **.peg** extension) and open it with PCIe Protocol Suite software.

Note: Please refer to the *PETrainer Scripting Language Reference Manual* for a comprehensive list of available commands and structures for PCIe and storage protocols.

4.6.1 Exporting a CATC Trace to a Traffic Generation File

A simple way to create a script file is to open a CATC Trace and then to export the CATC Trace data to a generation file:

1. Open a CATC Trace file.
2. Select **File > Export > to Generator File Format**.
3. Select the desired options from the File Export dialog box as shown below.




Figure 4.8: File Export As Generator Format Dialog.

Direction

Selects the direction of the traffic to be exported.

From and To

Selects a range for exporting. You can export all or part of the CATC Trace.

Do not export hidden packets

Ignores any packets hidden through the various hide options.

Do not export Idle packets

Excludes Idles from the export.

Export “Wait for Cpl” from upstream

Exports all **Wait for Completions** from the opposite direction. **Wait = TLP** is a script command.

Export “Wait for ACK” from upstream

Exports all **Wait for ACK DLLPs** from the opposite direction.

4.6.2 Saving a Script to a New File

To save a script file as a generation file:

1. Open an existing script file.
2. Select **File > Save As...** or click the **Save As**  button on the toolbar.




Figure 4.9: Save As Dialog.

3. Navigate to the desired folder and type a new file name where you want to save the current script, then click the **Save** button:

When the Save As command completes, the newly created script is displayed.

Note: The Save As dialog box includes the option **Save all included files**. This option causes the software to save any **Include** files that have been included in the script. The Included files are saved to the same directory as the traffic generation file.

4.6.3 Creating a New Empty Generation File

To create a generation file from scratch see the next section.

4.7 Generation Options Dialogs Overview

The Generation Options dialog box is used to configure settings of the device. If there are additional devices, you can control the settings separately of each device. Once the settings are changed you can save them as a default. When the application is launched the next time, the default settings are loaded.

These options are also used in a traffic generation script (for example, **Config = General** or **Config = Link**). This dialog duplicates the **Config** script command and is provided as a convenient alternative means of setting this command in the script.

Note: Generation Options together with Config Script commands define the Summit Z3 behavior as a device. Some configuration changes may require a link reset to ensure correct system operation. For example, changing lane reversal settings or changing available flow control values after the link has been established will cause problems with the link.

Note: The Generation Options dialog is subordinate to the script itself, so script commands override options selected in this dialog box.

4.7.1 Opening the Dialog

To open the Generation Options dialog (see [Figure 4.10 on page 44](#)) select **Setup > Generation Options** or click

the **Generation Options** button .

Dialog Layout

The Generation Options dialog is organized into seven tabs: **General**, **Link**, **Phy** (Physical) **Parameters**, **Integrity**, **Flow Control**, **Transactions** and **Low Power**.




Figure 4.10: Generations Options Dialog.

4.7.2 General

The general generation options can be selected on this dialog. The parameter values, defaults and description are given in the table below.

TABLE 4.1: General Generation Option Parameters

Parameter	Values	Default	Description
Target			Specifies the generation platform. The choice affects some of the options presented in the Generation Options dialogs.

Data Rate 2.5 GT/s Data Rate 5.0 & 2.5 GT/s Data Rate 8.0, 5.0, 2.5 GT/s	Selection	2.5GT/s	Specifies advertised data rate.
Link Width	1 2 4 8 16	1	Specifies the link width. Based on the Link Width you choose by selecting the radio button the settings on the Invert Polarity and Skew are enabled.
Disable Scrambling Tx	Yes No	No	Select to disable scrambling of the data that the Summit Z3-16 is transmitting (applies only to Gen1 and Gen2 data rates).
Invert Polarity Tx	From 0 to 15		Inverts the polarity of the selected lanes that the Summit Z3-16 is transmitting.
Invert Polarity Rx			Disabled for Summit Z3-16 as it automatically detects polarity of incoming data.
Emulation Role	Host or Device	Host	Select to specify Host or Device emulation.
Reverse Lanes (TX/RX)	Yes No	No	Select this option to emulate a host/device with reversed lanes. This option will reverse both RX and TX lanes to emulate a reversed link and test the DUT tolerance. If the link is actually reversed this option will cause the Z3 to not train properly.
Follow Lane Reversal	Yes No	No	When set, the Summit Z3-16 responds to lane reversal requests from the DUT. When cleared, the Summit Z3-16 Trainer does not follow the lane reversal protocol. Note: In this case the link may not be able to train.
Use External Reference Clock	Yes	Yes No	When unchecked, the Summit Z3 uses an on board clock (no SSC) that allows operation when there is no reference clock provided. When checked, the Z3 uses the reference clock from the bus. This allows for independent clocking operation when using the Summit Z3 Test Platform.

Analyzer Control	Yes	No	Gives you the option to: Start recording when generation starts. Stop recording when generation stops.
	No	No	

4.7.3 Link

The **Link** Generation Options dialog allows you to set up the link options. The parameters, values, defaults and descriptions are given in [Table 4.2, “Link Generation Option Parameters,” on page 47](#) below.

Generation Options

General Link Phy Parameters Integrity Flow Control Transactions

☒ Enable Automatic SKIP generation

SKIP 1360 symbols Gen 3: 370 blocks

Number of FTS ordered sets required (as sent in TS) :

2.5 GT/s : 255 5.0 GT/s : 255 8.0 GT/s : 255

Link Training Parameters

Gen3 Specification version: 1.0 Spec

☒ Skip Equalization in Link Training

☒ Skip EQ in Training Phase 2,3

☐ Enable Autonomous Speed Change

☐ Disable Auto Tx Presets

Save... Save As Default Load... OK Cancel

Figure 4.11: Generations Options Link Dialog.

TABLE 4.2: Link Generation Option Parameters

Parameter	Values	Default	Description
Enable Automatic SKIP Generation			
Enable Automatic SKIP Generation	Skip Timer in symbols	1360	Periodic timer that controls sending of SKIP ordered sets at specific intervals. The timer's value is measured in number of symbols for Gen1/Gen2 and in 130 bit blocks for Gen3.
	Gen 3 in blocks	370	
Disable Auto TX Presets			Disables auto transmit preset values
FTSCount	0 to 255	255	Number of FTS ordered sets required (as sent in TS)
Link Training Parameters			
Gen3 Specification version	0.7, Oct 09 0.7, Jun 09 0.71 Spec 1.0 Spec	1.0 Spec	Both versions of the specification are supported so you can choose either of them.
Skip Equalization in Link Training			The Summit Z3-16 will skip all equalization stages during Gen3 training.
Skip EQ in Training Phase 2, 3			The Summit Z3-16 will skip phase 2 and 3 equalization stages during Gen3 training.
Enable Autonomous Speed Change			Enables Autonomous Speed change support.
Disable Auto Tx Presets			Disables Autonomous Speed change support.

4.7.4 Phy Parameters

This tab displays the physical parameters of transmission and receiving. It allows you to select equalization parameters for transmitting and receiving lanes.

You can control lane parameters individually, or set them together by selecting the **Set All Lanes** check box.




Figure 4.12: Generations Options Phy Parameters Displaying Default Values.

TX Emphasis

Select the Preset, Preshoot and the De-emphasis values from the drop-down menu. The options are shown below.




Figure 4.13: Phy Parameters Displaying TX Emphasis Values.

TX Advertised

The Advertised value is the broadcasted value. You can also select a value from the drop-down menu as shown in [Figure 4.14 on page 50](#).




Figure 4.14: Phy Parameters Displaying TX Advertised Values.

RX DC Gain

Select the decibels from the drop-down menu. The options are shown below.




Figure 4.15: Phy Parameters Displaying RX DC Gain Values.

RX CTLE Gain

Select values from 0 to 15 from the drop-down menu.

RX Advertised

The Advertised value is the broadcasted value. You can also select a value from the drop-down menu as shown in Figure 4.16 on page 51.




Figure 4.16: Phy Parameters Displaying RX Advertised Values.

4.7.5 Integrity

The parameters, values, defaults and descriptions are given in [Table 4.3 on page 53](#).

Note: The Integrity page sets the parameters for two Config commands: **Config = TLP** and **Config = AckNak**




Figure 4.17: Generations Options Integrity Dialog.

TABLE 4.3: Integrity Generation Option Parameters

Parameter	Values	Default	Comment
ACK/NAK Policy			
Disable automatic ACK/NAK DLLP generation	Auto Ack Nak Disable	Auto	Auto - The Summit Z3-16 will send Ack or NAK according to the PCIe specification
Always ACK received TLP packets			Ack- The Summit Z3-16 will Ack all incoming TLP packets. Using this option will improve ACK latency of the Summit Z3-16, but does not guarantee reliable data transmission.
Always NAK received TLP packets			NAK - The Summit Z3-16 will NAK all incoming TLP.
Automatic ACK/NAK DLLP generation for received TLP packets (default)			Disable. The Summit Z3-16 will not send any Ack or NAK packets automatically. Ack and NAK packets can still be generated using a script.
TLP Policy			
Automatically generate TLP sequence numbers	Yes No	Yes	If not set, overrides automatic generation of the TLP sequence number and uses user-defined value of the field in the Packet=TLP commands. This option overrides any sequence numbers specified in the script.
Automatically generate TLP LCRC	Yes No	Yes	If not set, overrides automatic generation of LCRC and uses user-defined value of the field in the Packet=TLP commands. This option overrides any LCRC specified in the script.
Automatically retransmit TLPs that were NAKed or on replay timer expiration	In symbols Off	3150	Timeout in TLP transmitter path that counts time since last Ack or Nak DLLP is received. If set, automatically retransmit TLPs that were NAKed or on replay timer expiration.
User defined Replay Timer	In symbols Off	3150	If set, enable the user to define the Replay Timer.

Automatically retrain the link when number of retransmitted TLPs is 4	Yes No	Yes	If set, enable automatic retraining of the link in case the number of retransmitted TLP is 4. Valid only when AutoRetransmission is set.
---	-----------	-----	---

Tag generation policy for non-posted TLPs

Disable automatic tag generation	Yes No	No	Prevents the Exerciser from automatically inserting a tag. Tags are a sub-field of the transaction ID field. When auto tag insertion is enabled, the tag field is only modified for non-posted transactions such as CfgRd , CfgWr , and MemRd .
Use lower 5-bit of Tag field. Zero out higher 3 bits	Yes No	No	The Summit Z3-16 will automatically generate 5-bit TLP tags.
Use 8-bit of Tag field	Yes No	No	The Summit Z3-16 will automatically generate 8-bit TLP tags.

4.7.6 Flow Control

The parameters, values, defaults and descriptions are given in [Table 4.4 on page 56](#).

Note: The Flow Control page sets parameters for **Config = FCTx** and **Config = FCRx**.




Figure 4.18: Generations Options Flow Control Dialog.

TABLE 4.4: Flow Control Generation Option Parameters

FCRx Parameter	Values	Default	Comment
Tx Flow Control			
Do not send TLP packet if credit amount is insufficient	Yes No	Yes	When not set, the TLPs are being sent without the regard of how many credits are available. This option prevents TLP transmission if insufficient credits are available.
Rx Flow Control			
Periodically schedule UpdateFC DLLP	In ns (rounded to nearest 8) Off	4200	When enabled, allows automatic updating of these DLLPs. This option enables a periodic timer that controls sending of UpdateFC DLLPs. You should leave timer and credit values to defaults for correct behavior.
Initial Credits to Advertise			
PH	0 to 255	1	Posted Request Headers
NPH	0 to 255	1	Non-Posted Request Headers
CPLH	0 to 255	1	Completion Headers
PD	0 to 4095	1024	Posted Request Data Payload
NPD	0 to 4095	1	Non-Posted Request Data Payload
CPLD	0 to 4095	1024	Completion Data Payload

Note: Currently the Summit Z3-16 Exerciser does not support processing for nullified TLPs in the receiver path. This test scenario should be avoided.

4.7.7 Transactions Device Emulation

Select **Device** in the General tab to display the Host Memory Regions pane in the Transactions tab. When in Device Emulation mode, the Summit Z3-16 can automatically process incoming Configuration, Memory and IO read and write requests. This tab allows you to configure these options.

Generation Options

General | Link | Phy Parameters | Low Power | Integrity | Flow Control | **Transactions**

☐ Automatically handle Configuration Read and Write TLP transactions

☐ Automatically handle Memory and IO Read and Write TLP transactions

☒ Enable Memory and IO Completions with "Unsupported Request" (UR) Status

☐ Set "Data Poisoned" Bit for All Memory and IO Completions

☐ Automatically handle Expansion ROM

☐ Enable Fast Memory Completion:

Region	Address/Offset (hex)	Length (4KB Blocks)	PldGrowth	PldSeed (hex)
1 --Not Set--	00000000	0	Fixed Byte	000
2 --Not Set--	00000000	0	Fixed Byte	000
3 --Not Set--	00000000	0	Fixed Byte	000
4 --Not Set--	00000000	0	Fixed Byte	000
5 --Not Set--	00000000	0	Fixed Byte	000
6 --Not Set--	00000000	0	Fixed Byte	000

☐ Generate ECRCs

☐ Enable Precision Time Management

Save... Save As Default Load... OK Cancel

Figure 4.19: Generations Options Transactions Dialog - Device Emulation.

TABLE 4.5: Transactions Generation Option Parameters - Device Emulation

Parameter	Values	Default	Comment
Automatically handle Configuration Read and Write TLP transactions	Yes No	No	<p>If set, automatically handles Configuration Read and Write TLP transactions.</p> <p>For Configuration Read transactions, Completion TLP contains the data read from the internal Configuration Space according to the specified register address.</p> <p>For Configuration Write transactions, the internal Configuration Space is updated at the address with the data from Configuration Write TLP, and Configuration Write Completion is returned.</p> <p>This option enables Read and Write access to 4-KB configuration space.</p>
Automatically handle Memory and IO Read and Write TLP transactions	Yes No	No	<p>If set, automatically handles Memory and IO Read and Write TLP transactions.</p> <p>For Memory and IO Read transactions, Completion TLP contains the data read from the internal Memory/IO Address Space according to the specified address.</p> <p>For Memory and IO Write transactions, internal Memory/IO Address Space is updated at the address with the data from TLP.</p>
Automatically handle Expansion ROM	Yes No	No	<p>If set, automatically handles system Reads from Expansion ROM, using the base address programmed by the system in the Expansion ROM Base Address register in the configuration space of Device Emulation. The driver data could be programmed in the Expansion ROM address space using the Address Space Write functionality.</p>

4.7.8 Transactions Host Emulation

When in Host Emulation mode, up to three physical memory regions can be defined to be automatically handled by the Summit Z3 (see [Figure 4.20 on page 59](#)).




Figure 4.20: Generations Options Transactions Dialog - Host Emulation.

Select **Host** in the General tab to display the Host Memory Regions pane in the Transactions tab.

One 64-bit and two 32-bit regions can be specified. If a region is selected, the Physical Address for the start of the region has to be provided as well as the length in 4 KB blocks.

Read Completion Boundary for the Host (Root Complex) emulation can be specified as 128 or 64 bytes, as defined by the PCI Express specification.

Maximum Payload Size in bytes can be specified as 128, 256, 512, 1024, 2048, 4096.

When Host Memory Regions are selected, they are accessible for reading and writing by Write and Read Address Space buttons (see Exerciser Control Bar) as well as by AddressSpace = Write and AddressSpace = Read script commands. When the Device Under Test reads memory locations in the physical address range defined by one of the enabled regions, the data written there prior to that (from the application/script or by the device itself over PCI Express) is going to be returned.

Examples of using Host Memory Regions can be found in the SampleFiles\Z3-16TrainerScripts\NVMe_HostEmulation folder of the PCIe Protocol Suite software.

4.7.9 Transactions Fast Memory Completer

TABLE 4.6: Transactions Fast Memory Completer Parameters

Parameter	Values	Default	Comment
Enable Fast Memory Completer	Yes No	No	If set, enables the high-performance memory completer functionality.
Region	--Not Set-- Mem_64 Mem_32A Mem_32B Fixed_64 Fixed_32	--Not Set--	<p>A Region is a range of addresses in PCI Express memory space, which the high-performance memory completer handles using a defined policy.</p> <p>There are two region types:</p> <ul style="list-style-type: none"> The first type is defined by the fixed address location, such as Fixed_32 and Fixed_64, and can be used for both Device and Host Emulation. The second type is defined by the specific device memory space, such as Mem_64, Mem_32A, and Mem_32B, specified in the BAR setup in the Configuration Space Editor, and can be used only for Device Emulation. <p>The supplied Address is really the Offset from the beginning of the corresponding memory space. The actual address is calculated by the Summit Z3-16 Trainer when the BARs are configured.</p> <p>When a region is enabled, all Write data to the address range is consumed at high speed and discarded. All completion data for read requests is filled according to the rules specified by the PldGrowth and PldSeed parameters.</p> <p>Six regions are currently available for the fast memory completer.</p> <p>FastMemoryCompleter must be set to enable the Region.</p>

Address/ Offset (hex)	32-bit Address/ Offset 64-bit Address/ Offset	32-bit 0x000000 00	If the corresponding Region is set, based on the region type, this field is a 32-bit Offset for Mem_32A and Mem_32B, 64-bit Offset for Mem_64, 32-bit Address for Fixed_32, and 64-bit Address for Fixed_64. The corresponding Region must be set to enable the Address/Offset .
Length (in 4-KB blocks)	0 to 1,048,576	0	If the corresponding Region is set, this field specifies the length of the address range in 4-kilobyte blocks, starting from the address/offset, in the Address/Offset field, to which the fast memory completer responds. The corresponding Region must be set to enable Length .
PldGrowth	Fixed Byte Fixed DWord Incr Byte Incr DWord	Fixed Byte	If the corresponding Region is set, this field specifies the expected payload format. Fixed Byte and Fixed DWord specify a payload of a byte or dword pattern consisting of PldSeed . Incr Byte and Incr DWord specify a payload of incrementing bytes or dwords starting from zero. The corresponding Region must be set to enable PldGrowth .
PldSeed (hex)	8-bit value 10-bit value	0	If the corresponding Region is set and PldGrowth is set to Fixed Byte or Fixed DWord, this field species the byte value repeated for PldGrowth of Fixed Byte or the 10-bit dword value for PldGrowth of Fixed DWord. For other types of PldGrowth , this field is set to zero. The corresponding Region and PldGrowth must be set to enable Pldseed .
Generate ECRCs	Yes No	No	Enable if memory completions need to have ECRC appended. The TD bit will be asserted for the completions generated by the fast memory completer.

Note: In Device emulation mode, the current MaxPayload size set in configuration space will be used by completions from both firmware memory space and FastCompleter.

Note: In Host emulation mode, the RCB set in generation options will be used by completions. Z3 will follow the rules for aligning completion boundaries based on MaxPacket size (and RCB).

Example .gen File




Figure 4.21: Selecting Options to Enable Fast Memory Completer.

4.7.10 Transactions: Enable Precision Time Management (PTM)

Enable PTM

When enabled during Host emulation, directs the Z3 to respond to Precision Time Management (PTM) Request TLPs with PTM Response and PTM ResponseD messages as required. PTM Response will be sent for the first PTM Request received, and a PTM ResponseD for each PTMRequest received thereafter (see [Figure 4.22](#)).




Figure 4.22: Transactions: Enable Precision Time Management (PTM)

The Z3 maintains the Master Time in 4ns increments, and will generate the Propagation Delay and Master Time fields required for the PTM ResponseD message.

If the Enable PTM option is unchecked, all PTM Request messages will be ignored and no response will be generated.

In device emulation, the Enable PTM selection has no effect. In device emulation PTM Request messages may be generated via scripting.

4.7.11 Low Power

Select from the following options:

- ☐ L1 State Settings
 - Modes
 - ASPM (Active State Power Management)
 - PCIPM
 - Enable L1
 - L1 Sub States
 - Disable
 - Select L1_1 or L1_2
- ☐ Send PM ACKs in response to L1 ASPM requests (Host Emulation mode only)
- ☐ Enter a value for PM Ack/Nak Count (Host Emulation mode only)

Note: L1 sub states are enabled only for Z3 Trainers with CLKREQ# support.




Figure 4.23: Generations Options Low Power Dialog.

4.8 Generating Traffic: Set Generation Options

Before beginning generation, set options in the Generation Options dialog box. The steps below describe how to change the most common settings in order for the Z3 Trainer to operate with any device.

Change other options only if you need a different behavior from the default or if you are experiencing problems during operation.

1. Open the Generation Options dialog box by selecting **Setup > Generation Options** from the menu. The Generation Options dialog opens.
By default the General page displays.
2. Set the generation direction based on type of device you are emulating.
 - ☐ Host Emulation: Select Host
 - ☐ Device Emulation: Select Device
3. Set the maximum speed to be advertised by the trainer in the TS Data Rate options.
4. Set the maximum link width to attempt by the trainer in the Link Width options.
5. Click **OK** to apply all changes and close the Generation Options dialog.

4.9 Generating Traffic: Prepare Traffic Generation

To prepare for traffic generation, follow these steps:

1. If it is not running, start the PCIe Protocol Suite™ software.
2. Open an existing script file or create a new script. For example, open the traffic generation file **Exported.peg** by selecting **File > Open** from the menu. The following packets display in the main window (see [Figure 4.24 on page 66](#)).




Figure 4.24: Opening an Existing Script File.

The CATC Trace window shows the type of traffic that is to be generated in the current generation session.

3. If needed, make changes to the script file,

then save the file by clicking the **Save** button  .

4.10 Generating Traffic: Begin Traffic Generation


Perform the following steps to begin traffic generation:

1. Start generation by clicking the **Start Traffic Generation**  button on the Exerciser Control Bar.

This action causes the software to download the script to the device. After the download completes, the device starts executing the script.

As the script executes, the Exerciser Control Bar displays the script's progress.

The **Current script position** field displays the command description and CATC Trace packet number currently being generated.



Note: Script execution can be terminated at any time by clicking the

Stop Generation  button on the toolbar.


If a Wait command is executed where the Display parameter is specified, the user-defined text is displayed.

If a **wait=user** script command is executed, the script pauses until you click the

Resume Generation button  on the toolbar.

To run a new traffic generation file, do the following:

1. Select **File > New PErainer Script** or use the shortcut **Ctrl+N**.



2. An empty traffic generation file displays. You can also view the Script Editor (see [Figure 4.25 on page 68](#)).




Figure 4.25: Empty Traffic Generation File.

4.11 Editing Generation Files with the Script Editor

The Script Editor is an editing tool for traffic generation files (<filename>.peg). The generation script is presented in the Script Edit window. Parameters are presented in menus and text boxes in the Command Properties window in the right-hand portion of the Script Editor.

To launch the Script Editor: click the **Script Editor** button  on the toolbar or right-click the CATC Trace window and choose **Edit as Text** from the pop-up menu.

The Script Editor window displays in the lower portion of the CATC Trace window.




Figure 4.26: Script Editor Window.

Layout: The Script Editor divides into four areas:
















- ❑ **Script Editor toolbar:** Presents options for printing, saving, bookmarking, and other options.
- ❑ **Script Edit window:** Main window where the script is displayed and edited. Text in this window behaves as in most text editors. Text can be copied, pasted, and searched.
- ❑ **Command Properties window:** Presents editable parameters. Many parameters have menus. Click the parameter in the Command Properties window to see if a down-arrow appears.
- ❑ **File tabs:** Lists the name of the traffic generation file and any open **Include** files that are associated with the generation file. If the generation file has **Include** statements, the **Include** files automatically open and display as tabs in the File tabs section of the Editor window.

Error Log: An error log opens automatically at the bottom of the window any time a script error occurs. The window closes automatically whenever the error is corrected, after you save the script.

4.11.1 Script Editor Toolbar

The toolbar contains buttons for saving your edits, navigating, searching and other functions.



	Save. Saves your edits and immediately updates the setting bars and Frames shown in the CATC Trace window.		
	Go to Trace View. Causes trace view to bring the currently selected script line to the top of the screen.		Toggle Bookmark. Allows markers to be set or removed to aid in navigation.
	View Options. Opens a menu with three options: Enable Outlining Toggle Outlining Line Numbers. See “View Options Menu” on page 74 for descriptions.		Next Bookmark.
	Cut.		Previous Bookmark.
	Copy.		Clear All Bookmarks.
	Paste.		Find.
	Undo.		Replace. Find and replace.
	Redo.		Print.

4.11.2 Script Edit Window


The Script Edit Window offers several features to simplify the process of editing.

Syntax Highlighting

All known commands and parameters are highlighted in **blue**.


All predefined values and command modifiers are highlighted in **brown**.

Intellisense prompts for known predefined values/literals. This functionality is invoked when you type = after a known key or select **List values** from the Context menu.




Tooltips

The Tooltips look like the following:



Outlining

When outlining is enabled the user has the option to **collapse/expand** code blocks:



Text Editing Commands


The Script Editor supports standard editor commands:

- ☐ Copy/Paste
- ☐ Undo/Redo
- ☐ Find/Replace
- ☐ Bookmarks


Synchronized Scrolling with the CATC Trace Window

You can navigate from the generation code window to the corresponding place in the CATC Trace representation, and vice versa.

From the CATC Trace window, right-click the **first cell in a packet** in the CATC Trace window and select **Go to Script Editor** from the pop-up menu. The Script Editor window then repositions to the corresponding code.




From the script editor, right-click some **code** within the Script Editor window and select **Position Trace view on packet x** from the pop-up menu (where **x** is a packet number). The CATC Trace window repositions to the corresponding packet number (see the following figure on the next page).





4.11.3 Command Properties Window

The Command Properties window lists all possible parameters for the current script command and all values for the parameters currently defined in this command. Entering parameters/values within the Edit window causes the Command Properties window to

automatically update. Parameters/values can be changed by entering text into the text boxes or by selecting items from pull-down menus as shown in the example below.



In this case, the edit window is updated automatically. If the current script command does not have parameters or the current cursor position is outside of any script command, then a generic prompt is displayed in the window:



4.11.4 Script Editor File Tabs


At the bottom of the Script Editor window is the name of the open generation file.

If there are **Include** statements in the generation file that link it to other generation files, these files automatically open and display as tabs at the bottom of the window. You can click the tabs to toggle between the open generation files.



4.11.5 Script Editor Error Log

Whenever you create a scripting error, a log opens at the bottom of the application window. When the error is corrected, the window automatically closes.



Errors: Marked by red squares.


Warnings: Marked by yellow squares.

Double-clicking an error in the error log causes the cursor in the edit window to move to where the error was detected.

Note: You cannot run the script if it has syntax errors.

4.11.6 View Options Menu

The **View Options** button displays a menu with these options:



Enable Outlining: Adds an expandable/collapsible tree structure to the left side of the Script Editor showing the hierarchical relationships of the script lines.

Show Line Numbers: Adds line numbers to the left side of the Script Editor window.

Show Tooltips: Allows tooltip pop-ups, which provide descriptions of script keywords when cursor mouses over a keyword.

Toggle Outlining: Toggles the outline tree between collapsed and expanded states.

Chapter 5

Macros

5.1 Macros



You can add buttons to the Status bar at the bottom of the window (and add commands to the Generate menu) to run traffic generation macros on the Exerciser.

After a macro script has been defined and assigned to a button on the Status bar, the macro can be run by clicking the macro button with the mouse or selecting the macro name from the Generate menu.

5.1.1 Default Macros: Connect and Disconnect

By default, the PCIe Protocol Suite™ software includes two macros, Connect and Disconnect. These buttons execute macros for creating and breaking a connection between the Exerciser and a DUT.

The buttons are on the Status bar when Exerciser hardware is present. The commands are also on the Generate menu:



5.1.2 Connect Macro

The default code for this macro is the following:

```
Config = General {TrainerReset = 1}  
Link = Detect  
Wait = 500  
Link = L0  
Wait = 500  
Link = InitFC
```

5.1.3 Disconnect Macro

The default code for this macro is the following:

```
Config = General {TrainerReset = 1}  
Link = Detect
```


5.1.4 Adding New Script Macros

There are two ways to add script macros:


- ☐ Using the Generation Macros dialog
- ☐ Adding script files to the GenScriptMacros directory.

Using the Generation Macros Dialog


1. Open the Generation Macros dialog by selecting **Setup > Generation Macros** from the menu.



2. In the Generation Macros dialog box, click the **New** button.



3. Within Script properties area specify **script name**, **script comment**, **script icon**, and **whether or not to show script icon** on a toolbar.
4. Create a new icon for the script by clicking **Edit Icon...** button. The Edit Generation Macro Icon dialog displays.



5. Using the tools provided, paint the icon for new script macro and then press **OK**.
6. Edit the script code by clicking the **Edit code...** button. The dialog closes and an empty script editing window appears (see [“Editing Generation Files with the Script Editor”](#) on page 69).

7. Type the script code and press the **Save** button. The script macro and icon are saved in the GenScriptMacros directory located under the PCIe Protocol Suite directory (for example, Program Files\CATC\PCIe Protocol Suite\GenScriptMacros).
8. Close the script window. The new macro script button automatically appears on the Status bar at the bottom of the window. Clicking this button causes the Exerciser to execute the script.

Adding Script Files to the GenScriptMacros Directory

The second way to add a new script macro is to copy an existing script file in the GenScriptMacros directory.

1. Copy a script file into the GenScriptsMacros directory located under the PCIe Protocol Suite directory (for example, Program Files\CATC\PCIe Protocol Suite\GenScriptMacros).
2. Switch to the PCIe Protocol Suite application. You see that a new icon has been automatically added for the script file to the Status bar at the bottom of the window. The default icon is assigned to the new script macro and the file name is used as a script name.

5.1.5 Modifying Script Macros

To modify a macro assigned to a button:

1. Select **Setup > Generation Macro** from the menu to open the Generation Macros dialog for modifying, creating, and deleting macros:
 - ☐ **Name:** Name of Macro
 - ☐ **Comment:** Descriptive comment so you can remember what the macro does
 - ☐ **Icon:** Currently assigned button for the macro.
 - ☐ **Show icon on the toolbar:** If checked, places the icon on the Status bar.
 - ☐ **Edit Code:** Opens a dialog for editing the macro script.
2. Select the macro to be modified.
3. Within the Script properties area, modify the script name, script comment, script icon, and whether or not to show script icon
4. To edit script code, press the Edit code... button. The Generation Macros dialog closes and the Script Editing window appears, showing current code for the selected script macro.

Note: If the Generation Script Editor pane does not appear, click  .

5. Modify the script code and press the Save button .
6. Close the script window. The macro has now been modified.

5.1.6 Changing the Order of Macro Icons on the Status Bar

To change the order of script macro icons on the Status bar:

1. Open Generation Macro Scripts dialog by selecting **Setup > Generation Macros**.

2. Click the Up and Down buttons to change the order of the script macros.
3. Close the dialog. The button order is changed.

5.1.7 Deleting User-Defined Script Macros

To delete a script macro:

1. Open the Generation Macro Scripts dialog by selecting **Setup > Generation Macros**.
2. Select the macro you want to delete and press the Delete button:

All deleted scripts and icons are removed from GenScriptMacros directory. A backup copy is stored in the GenScriptMacros\Deleted directory.

Note: You cannot delete the Connect and Disconnect script macros.

5.1.8 Restoring the Default Appearance of the Connect and Disconnect Icons

You can restore the default appearance of the Connect and Disconnect icons by clicking the Restore button.

1. Open the Generation Macro Scripts dialog by selecting **Setup > Generation Macros**.
2. Select the macro you want to restore and press the Restore button.

Configuration Space

For Device Emulation, *PETrainer™* provides features to emulate Address Spaces of a PCI Express device, including Configuration, Memory, and IO spaces. The following two chapters describe how to set up, configure, and manipulate Address Spaces.

6.1 Configuration Space Editor

The Configuration Space Editor allows the Configuration Space to be modified on a field-by-field basis using hexadecimal or binary format.

The editor supports PCI-compatible Configuration Spaces and PCI Express enhanced Configuration Spaces.

6.2 Launching the Configuration Space Editor

Selecting **Tools > Configuration Space Editor** displays the following dialog:




Figure 6.1: Configuration Space Editor Dialog.

- ❑ **Create new Configuration Space File:** Opens the Configuration Space Editor with the default (empty) configuration space.
- ❑ **Open existing Configuration Space File:** Activates the list of recently used configuration space files and enables the **Select...** button. After you select a file and click OK, the Configuration Space Editor displays.

6.2.1 Configuration Space Files

You can save configuration space files in the Configuration Space View. Open a trace file, select a packet, and then select **Reports > Configuration Space View**. Click the **Save** button to display the Save As dialog and enter a file name (which has no special file extension).

You can save configuration space files in the Configuration Space Editor. Click the Save button to display the Save As dialog and enter a file name (which has no special file extension).

You can open saved configuration space files in the Configuration Space Editor and optionally edit them. You can then use them for generation.

6.2.2 Editing

When a new file is created, a blank PCI Configuration Space Header is loaded for editing. However, its position is not configurable, and the offset always starts at 000h.




Figure 6.2: Configuration Space View.

In the Configuration Space View, on the left, you can add and define PCI-compatible or PCI Express Configuration-Space Capability Structures.

The toolbar allows you to create a New configuration space, Open a configuration-space file, Save a file, Write Configuration Space, and Read Configuration Space.

Click **+ Add** and then choose a Capability Structure from the context menu. You can also select **Edit > Add PCI Capability** or **Edit > Add PCI Express Capability**.

Available PCI Capability Structures are:

- ☐ PCI Power management
- ☐ Message Signaled Interrupts
- ☐ Accelerated Graphics Port
- ☐ Vital Product Data
- ☐ Vendor-Specific
- ☐ PCI Express
- ☐ Hyper Transport
- ☐ MSI-X PCI Extended
- ☐ Generic

Available PCI Express Capability Structures are:

- ☐ Advance Error Reporting
- ☐ Virtual Channel
- ☐ Virtual Channel for MFVC
- ☐ Device Serial Number
- ☐ Power Budgeting Capability
- ☐ Root Complex Link Declaration
- ☐ Root Complex Internal Link Control
- ☐ Root Complex Event Collector Endpoint Association
- ☐ Vendor-Specific
- ☐ RCRB
- ☐ ACS
- ☐ MFVC
- ☐ L1 PM Sub states
- ☐ Resizable BAR
- ☐ TPH Requester
- ☐ LTR
- ☐ Page Request
- ☐ Multicast
- ☐ PASID
- ☐ M-PCIe Extended
- ☐ DPA
- ☐ SR IOV
- ☐ Secondary PCIe Extended
- ☐ ATS
- ☐ TPH
- ☐ ARI
- ☐ Generic

Selecting a structure displays a dialog in which you can define the structure. See the following figure.




Figure 6.3: Add Capability Structure.

Enter an integer **Offset**.

Position the structure in the linked list of capabilities by selecting the Previous and Next capability structures.

Note: User-defined structures can be added to the above set of supported structures ([“Configuration Space Decoding” on page 99](#)). The Configuration Space View, from the Reports menu, reflects any added structures.

After you click **OK**, the center column displays the Capability Structure View, with the register layout. You can modify the selected Capability Structure by selecting registers and editing in binary or hex. The toolbar allows you to select Binary or Hexadecimal for editing.




Figure 6.4: Capability Structure View.

Alternatively, after selecting a register, you can modify the register in the Field View in the right column.

The Field View allows you to override field attributes. By default, attributes are assigned according to the specification. The available options are:

- ☐ **RO**: Read Only
- ☐ **RW**: Read-Write
- ☐ **RW1C**: Write-1-to-Clear




Figure 6.5: Field View.

6.2.3 BARs Setup

The BARs Setup dialog helps set up Base Address Registers. It provides a more convenient way of defining BARs than setting up the BARs manually. In addition, it provides the mapping of BARs to PETrainer and Summit Z3-16 memory regions.

To open the BARs Setup, select **Edit > BARs Setup**.




Figure 6.6: BARs Setup Dialog.

BAR1 and BAR2 are assigned to 64-bit memory address space and mapped to Mem64 PETrainer memory region. BAR4 is assigned to 32-bit memory address space and mapped to Mem32A PETrainer memory region.

You can specify Prefetch and Address Space Size. The sizes for each address space are limited to the values supported by PETrainer hardware.

BAR and Prefetch fields affect the Hexadecimal/Binary in the middle column of the Configuration Space Editor.

Size field affects Field View in the right column of the Configuration Space Editor.

The mapping of BARs to *PETrainer* memory regions is discussed at the AddressSpace Command in the Help section of the *PETrainer* Script Language.

The BARs settings are used for Memory and IO completer.

6.3 Configuration Read and Write

PETrainer™ can automatically handle Configuration Read and Write TLP transactions:

For a Configuration Read transaction, the Completion TLP contains the data read from the internal Configuration Space according to specified register address.

For a Configuration Write transaction, the address for the internal Configuration Space is updated with the data taken from Configuration Write TLP, and Configuration Write Completion is returned.

You can specify the initial Configuration Space by editing the **AddressSpace=Write** command directly in the script or by using the UI provided in the Generator toolbar.

The PCIe Protocol Suite™ software provides a special editor for editing this file called the Configuration Space Editor (see [“Launching the Configuration Space Editor” on page 83](#)).

6.4 Expansion ROM Setup

Perform the following steps to properly setup the Expansion ROM:

1. Load a file or create a new configuration space.
2. In the configuration space editor, **select expansion rom register**.
3. Then select the size to be used (see [Figure 6.7 on page 89](#)).




Figure 6.7: Setup.

4. Save the configuration space once all the required changes to the configuration space are entered.
5. Follow the usual sequence to load configuration space file to the Z3 Trainer Summit which is writing the configuration space.




Figure 6.8: Write Address Space.

6. Click on the **icon** to write the address space.
7. If there is a predefined file for the expansion rom contents select the **Exp ROM** check box.
8. Enter the path to the file.
9. Enter any offset or size required.


Chapter 7

Address Spaces


7.1 Memory/IO Space Editor

The Memory/IO Space Editor lets users write address space memory into the Exerciser and read address space memory from the Exerciser.

To access the Memory/IO Space Editor, select **Tools > Memory/IO Space Editor**. The following dialog displays:





- ❑ **Create new Address Space File:** Opens the Memory/IO Space Editor and displays an empty address space with the size specified.
- ❑ **Open existing Address Space File:** Activates the list of recently used Memory/IO Address Space files and enables the Select... button. After you have selected a file and then clicked Select, the Memory/IO Space Editor displays.



The Memory/IO Address Space editor is implemented as a standard hex editor.

The address space memory must be saved to a file so that it can be downloaded to the hardware using the PCIe Protocol Suite™ application.

If you prefer, you can write address space memory into the Exerciser and read address space memory from the Exerciser directly using the  and  toolbar buttons or using the menu **File > Write Address Space** or **File > Read Address Space**.

7.2 Memory Regions for Host Emulation

Please refer to [“Transactions Host Emulation” on page 58](#).

7.3 Using StoreData in Device Mode for Z3 Scripting

Memory Reads executed from Z3 script can have an optional parameter called StoreData. For a description of this parameter please refer to 3.1 Packet = TLP on page 6 of the PETrainer Scripting Language Manual.

When this parameter is used it instructs the Trainer to collect all the data returned as a response to this Memory Read and copy it to the specified Address Space location (or Host Memory Region).

The following describes in detail the steps that should be taken in the case of Device Emulation in order to set up the exerciser to be able to use the StoreData parameter and to verify the results of running the scripts with this parameter.

To use StoreData perform the following steps:

1. Select **Setup> Generation Options** to display the Generation Options dialog:
2. Select the General tab and click **Device** in the Emulation Role pane (see [Figure 7.1 on page 93](#)).




Figure 7.1: Generation Options - Device Emulation.

3. Select the Transactions tab and select the options shown in [Figure 7.2 on page 94](#). Click OK.




Figure 7.2: Generation Options - Transactions Tab.

4. You need to have a configuration space file ready before setup to map the BAR correctly to the PETrainer Memory Region. Save the config.bin in an appropriate folder.
5. Select **Tools > Configuration Space Editor**, to open the Configuration Space Editor dialog (see [Figure 7.3 on page 95](#)).
6. Click **Edit > BARs Setup...** to display the BARs Setup dialog (see [Figure 7.3 on page 95](#)).




Figure 7.3: Generation Options - Transactions Tab.

7. Edit the address mapping as required and save the configuration.
8. Write the Configuration Space file to the Summit Z3 Exerciser as shown below.




Figure 7.4: Writing Configuration Space File.

9. Run the MemRd script with StoreData and the completion payload will move to the local Summit Z3 memory (see [Figure 7.5 on page 96](#)).




Figure 7.5: Completion Payload.

10. The Read Address Space now shows the payload in the memory.




Figure 7.6: Read Address Space.

Updates and Licensing

8.1 Updating the Exerciser

BusEngine™ and/or Firmware updates are now automatic processes that run anytime a new version of the PCIe Protocol Suite™ software is installed that is incompatible with the currently installed BusEngine or Firmware. The update process generates on-screen instructions.

If, however, you need to manually perform BusEngine or Firmware updates, follow these steps:

1. Select **Setup > Update Device ...** from the menu to display the Update Analyzer dialog for Summit Z3-16™.
2. Select the appropriate file locations for the Firmware and/or BusEngine, using Browse, if necessary.
3. Check the appropriate options (if in doubt, check all options).
4. Click **Update Selected** or **Update All** to initiate the updating of the Exerciser.

8.2 License Keys

A License Key is necessary to enable software maintenance. If you attempt to generate traffic with the Exerciser without an installed License Key, a message appears to indicate that a License Key is necessary in order to record traffic.

A License Key must be obtained from Teledyne LeCroy for each Exerciser.

After you obtain the License Key, follow these steps to install it:

1. Select **Help > Display License Information...** from the menu bar to display the Update License dialog.
2. Click the Install License File... button to display the Select License Key File dialog and enter the path and filename for the License Key to navigate to the directory that contains the License Key.
3. Select the **.lic** file, and then click **Open**.

You can also update your licensing information by selecting **Setup > All Connected Devices ...**, then clicking Update License.

8.3 License Information

You can view Licensing information for your Exerciser by selecting **Help > Display License Information...** from the menu bar. The License Information window displays data about the maintenance expiration and purchased features.

Appendix A

Configuration Space Decoding

The decoded capability structures in the Configuration Space Viewer and Editor are based on programmed definitions in the PCIe Protocol Suite software and on Configuration Space Decode Scripts.

Configuration Space Decode Scripts are tools to define capability structures and instruct the Configuration Space Viewer or Editor how to decode them. These scripts are in the **\CfgSpaceScripts** sub-directory below the **\Scripts** directory in the application directory.

You can write Configuration Space Decode Scripts using the CATC Scripting Language (CSL). See the *Teledyne LeCroy Analyzers File Based Decoding Manual* for reference.

PCI Express Configuration Space Decode Scripts have the file extension **.pecfgdec**.

A.1 Mandatory Definitions

Configuration Space Decode Scripts must set the following reserved variables.

- ❑ **CapabilityName**: Name of the capability structure
- ❑ **CapabilityID**: ID of the capability structure
- ❑ **ExtAddSpace**: Set to 1 if Extended Configuration Space. Otherwise, set to 0 for PCI.

A.2 Mandatory Module Functions

- ❑ Modules are collections of functions and data dedicated to decoding a specific capability structure. Each module has one primary Configuration Space Decode Script file (extension **.pecfgdec**) and optionally has include files (**.inc**).
- ❑ A module function is an entry-point into a decoding module. To help display a capability structure, the application calls a module function.
- ❑ The Configuration Space Editor and Viewer support only the **DecodeRegister(offset)** and **GetSize()** functions.

A.2.1 DecodeRegister(offset)

The application calls this function while decoding a specific DWORD offset of the specified CapabilityID. The offset is the decoding entry point, where the decoding path starts.

The Configuration Space Editor calls this function to determine how to decode the assigned configuration space. The **offset** parameter is the DWORD to decode. An offset of 0 indicates bytes 00h-03h, an offset of 1 indicates bytes 04h-07h, and so on.

Note: The Configuration Space Editor can only decode one DWORD at a time.

A.2.2 GetSize()

This function returns the size of the capability structure specified by CapabilityID.

A.3 Configuration Register Types

The following reserved variables are defined global constants.

- ❑ CFGREG_UNDEFINED
- ❑ CFGREG_HWINIT
- ❑ CFGREG_RO
- ❑ CFGREG_RW
- ❑ CFGREG_RW1C
- ❑ CFGREG_ROS
- ❑ CFGREG_RWS
- ❑ CFGREG_RW1CS
- ❑ CFGREG_RSVPD
- ❑ CFGREG_RSVDZ

Note: These reserved variables match the Configuration Register Types of Table 7-2 in Section 7.4 of the PCI Express Base Specification, Rev. 2.1.

A.4 Primitives

Decoding uses the following primitives.

GetRegisterField(dword_offset, bit_offset, field_length)

This function returns a register field of length **field_length**, starting at bit position **bit_offset** in DWORD **dword_offset**.

- ❑ **dword_offset**: DWORD offset of the register field location
- ❑ **bit_offset**: Bit offset of the register field location
- ❑ **field_length**: Length of the register field

For example, **GetRegisterField(1, 9, 2);** means: Go to DWORD 1, bit offset 9, and returns 2 bits.

AddField(field_name, field_length, configuration_reg_type, tooltip, encoding_table = NULL)

This function adds a register field to the Capability View and returns a pointer to the field, for adding subfields.

- ❑ **field_name**: Name of the register field to display in the Capability View
- ❑ **field_length**: Length of the register field

Note: configuration_reg_type: Configuration register type of the register field.

Note: If subfields are defined, their configuration register types override this setting for their specified bits.

- ❑ **tooltip**: Tooltip displayed for the register field in the Capability View
- ❑ **encoding_table**: Optional. Displays encodings as lists for select values.
- ❑ For example, user input becomes a combo box for the field in the Field View.

As examples:

AddField("PCI Express Extended Capability ID", 16, CFGREG_RO, "");

means: Add the field "PCI Express Extended Capability ID" with length 16 and cfg register type CFGREG_RO.

capability_reg = AddField("Capability Register", 32, CFGREG_RW, "");

means: Added the field "Capability Register" with length 32 and cfg register type CFGREG_RW and stored a pointer to this field in variable capability_reg, which can be used to add subfields to this field.

AddSubField(parent_field, subfield_name, subfield_length, configuration_reg_type, tooltip, encoding_table = NULL);

This function adds a subfield to a register field in the Capability View. Subfields are modifiable and visible in the Field View and appear in the tooltips of register fields.

- ❑ **parent_field**: Pointer to a register field in the Capability View
- ❑ **subfield_name**: Name of the subfield, displayed in the Field View
- ❑ **subfield_length**: Length of the subfield
- ❑ **configuration_reg_type**: Configuration register type of the subfield field.

Note: This overrides the configuration_reg_type of the parent field.

- ❑ **tooltip**: Tooltip displayed for the subfield in the Capability View
- ❑ **encoding_table**: Optional. Displays encodings as lists for select values.
- ❑ For example, user input becomes a combo box for the field in the Field View

For example,

AddSubField(capability_reg, "Mode Supported", 4, CFGREG_RO, "Indicates the Function modes,"), ModeEncodings);

means: Add the subfield "Mode Supported" to the parent field "capability_reg" with length 4, type CFGREG_RO, a tooltip in the Capability View, and a combo box displaying "mode encodings" for input in the Field View.

A.5 Helper File

ConfigSpaceCommon.inc include file contains useful functions for script decoding.

Appendix B

NVMe Drive Emulation

B.1 NVME Drive Emulation in Windows 7

To perform NVME drive emulation in Windows 7 perform the following steps:

1. Copy the content of C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation\Drivers\Windows7 somewhere on a PCIe system with Windows 7 64-bit.

Note: For NVMe drive emulation in other windows and Linux environments refer to the corresponding folders under C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation\Drivers\


2. Turn the system off.
3. Insert Z3 in the T3 interposer in a slot on this PCIe system. Keep the system turned off. If you are not using a T3 Analyzer just insert the Z3 directly in the PCIe slot from the host system.
4. Load dev.gen generation options (this configures Z3 for Device Emulation) from location C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation
5. Write the configuration space and Identify data:

Cfg:


C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\
Z3-16TrainerScripts\NVMe_DriveEmulation\nvme_drive_config_space.dat

Mem32B:

C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\
Z3-16TrainerScripts\NVMe_DriveEmulation\nvme_identify_data.dat
Use memory size 0x00002000




6. Load the Drive Script from C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation\start_nvme_drive.peg
7. Run the C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation\start_nvme_drive.peg script to start NVMe emulation.
8. Press the **Connect** button in the Generation bar.
9. Start recording. (Perform this step only if use of the protocol analyzer is required.)
10. Boot the PCIe system.
11. When New Device notifications appear, point the driver installation to the location where you copied files in step 1, using "Have Disk". Go through the wizard to complete the installation.
12. Make sure the LeCroy drive has appeared in the Device Manager. (See figure below, but "NVMe NVMeLecroy000000 SCSI Drive" in "Disk drives" and also "Community NVMe Storport miniport" under "Storage Controllers").




13. Go to Computer Management and select **Disk Management**.


14. The manager will prompt to set the Master Boot Record on the new drive. Click **OK**.
See figure below.




15. The drive is un-partitioned. Right-click and select **New Simple Volume....**



16. Follow the wizard, and select **FAT32**. See the screen below.



17. Wait till the formatting finishes and the new volume will display. Now the files can be copied to and from the volume.



Note: If something goes wrong, and the system preforms Startup Recovery after restart, you might need to install the driver again. In this case at step 7 the device will appear in the Device Manager just as a "PCI Device". Perform the following steps if this occurs:

1. Right-click on it and select **Update Driver**.
2. Select **Let me choose the driver for this device....**
3. After the list of device appears proceed to **Have Disk** and press on it.
4. Browse to the folder "NVMe" on desktop.
5. Select **nvme** INF file.
6. Click **OK** for everything.
7. Make sure you are at step 7 in Device Manager and proceed.

B.2 NVME Drive Emulation in Ubuntu Linux 14.10 and Linuxv3.1-rc4

Note: Before running the system and installing the NVME drive, ensure that you have finished setting up the Summit Z3 and Summit T3 analyzer configuration. Once the Z3 has finished running the start_nvme_*.peg script and the link is established you can follow the steps below.

To perform NVME drive emulation in Ubuntu Linux 14.10 and Linux v3.1-rc4 perform the following steps:

1. Install Ubuntu <http://releases.ubuntu.com/saucy/> desktop image for 14.10.
2. Install (or verify if they are already installed) in all necessary environment:
 - ☐ Linux headers


```
# sudo apt-get install Linux-headers-$(uname -r)
```
 - ☐ GNU make and C++ compiler (g++)


```
# sudo apt-get install build-essential
```

Note: In case you see the error consider updating to the latest linux packages by sending the command: `#sudo apt-get update` (this will update to latest changes in Linux software).

3. Once the image is installed the native file `nvme.ko` will be present in the system which can be used to run NVMe device emulation.

If the file `nvme.ko` cannot be located, mount the file as follows:

- ☐ In the command prompt issue : `locate nvme.ko`
- ☐ Issue a command : `insmod ../path/nvme.ko`


Note: Please note that in some cases you will see two instances of the same file, please select the latest version of the same file

- ☐ To remove the module and install new one issue: `rmmod nvme.ko`
4. In addition, Linux-nvme support can be installed with latest changes from:
<http://git.infradead.org/users/willy/Linux-nvme.git>
 - a. In order to install, please install GIT module into the Linux host machine:
Issue a command:
`git clone git://git.infradead.org/users/willy/Linux-nvme.git` to install latest Linux_nvme git
 - b. Once this is installed please issue the following command:
`locate nvme.ko` to locate the driver.
 - c. Make sure it is mounted and if necessary issue `insmod nvme.ko`.
 5. Power down the system and start configuration for the NVMe Z3 device to work as a Device Emulator. In order for the Teledyne LeCroy Z3 system to work as a device emulator you will need a host machine with Teledyne LeCroy software installed.


Note: In order for the Teledyne LeCroy Z3 system to work as a device emulator you will need a host machine with Teledyne LeCroy software installed.

B.2.1 Hardware Setup for Test Equipment


1. **Insert the Z3 in a slot of the PCIe system under test. Keep the system turned off.**
 - ☐ **If you have a T3 analyzer, insert the interposer first into the system's slot and then plug the Z3 on top of the interposer.**
2. **Open PCIe Protocol Suite in a separate system running windows.**
3. Power on the Z3 System and the analyzer if available.
4. Once the Z3 and the analyzer are discovered by the PCIe Protocol Suite software, start the configuration process as explained below.
5. Click **Setup > Generation Options** and select **Device** to setup the Z3 to act as a Device.




6. Configure the Transactions layer for the Z3 Trainer. See the screen on the next page.



7. Once the Z3 is setup, set up the recording options for the analyzer, if available, by clicking **Setup > Recording Options**. See the screen on the next page.



An example of a trigger to see the transactions issued by the Z3. See the screen on the next page.




8. Setup the Z3 Configuration Space and Memory Space by loading
\\Users\\Public\\Documents\\LeCroy\\PCIe Protocol Suite\\Sample Files\\Z3-16TrainerScripts\\NVMe_DriveEmulation\\nvme_drive_config_space.dat

The Write Address Space dialog box is shown. The 'File Path' field is highlighted with a red box and contains the path: C:\Users\Public\Documents\LeCroy\PCIe Prot...


	File Path:	Offset (bytes):	Size (bytes):
<input checked="" type="checkbox"/> Cfg :	C:\Users\Public\Documents\LeCroy\PCIe Prot...		
<input type="checkbox"/> Mem64 :		0x00000000	0x20000000
<input type="checkbox"/> Mem32 A :		0x00000000	0x08000000
<input type="checkbox"/> Mem32 B :		0x00000000	0x08000000
<input type="checkbox"/> IO A :		0x00000000	0x00000100
<input type="checkbox"/> IO B :		0x00000000	0x00000100
<input type="checkbox"/> Exp ROM:		0x00000000	0x01000000


Buttons at the bottom: Write, Cancel.

9. Load the Identify data file from C:\Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation\nvme_identify_data.dat




10. Issue the Write command to Z3 Address Space.
11. Load the script from \Users\Public\Documents\LeCroy\PCIe Protocol Suite\Sample Files\Z3-16TrainerScripts\NVMe_DriveEmulation\start_nvme_drive.peg and run the script.





12. Once the script has finished running, send out the link up command.



13. Start the system under test and power it up to Ubuntu. Open up the command prompt terminal (CTRL+ALT+T).

14. In the command prompt, switch to the root port permissions: `sudo su`

15. Once this is done, check and locate `nvme.ko` : `locate nvme.ko`. Ensure that the driver is mounted and if necessary issue: `insmod ../path/nvme.ko`

16. To create the drive: Sudo `fdisk /dev/nvme0n1`. Once the command is issued you will be prompted to create the new drive. Select default versions and ensure that the disk is writable.
17. To create a partition: `sudo mkfs.ext4 /dev/nvme0n1` and select default options.
18. Once this is done you can start using read/write commands to read and write to this drive.

Appendix C

China Restriction of Hazardous Substances Table

The following tables are supplied in compliance with China's Restriction of Hazardous Substances (China RoHS) requirements:

部件名称	有毒有害物质和元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCBAs	X	O	X	X	X	X
机械硬件	O	O	X	O	O	O
金属片	O	O	X	O	O	O
塑料部件	O	O	O	O	X	X
电源	X	X	X	O	X	X
电源线	X	O	X	O	X	X
保护外壳(如有)	O	O	O	O	X	X
电缆组件(如有)	X	O	X	O	X	X
风扇(如有)	X	O	X	O	X	X
交流滤波器和熔丝组件(如有)	X	O	X	O	O	O
外部电源(如有)	X	X	X	O	X	X
探头(如有)	X	O	X	O	X	X
O: 表明该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求之下。						
X: 表明该有毒有害物质至少在该部件的某一均质材料中的含量超过 SJ/T11363-2006 标准规定的限量要求。						

EFUP (对环境友好的使用时间) 使用条件: 参阅本手册“规范”部分规定的环境条件。

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr ⁶⁺)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCBAs	X	O	X	X	X	X
Mechanical Hardware	O	O	X	O	O	O
Sheet Metal	O	O	X	O	O	O
Plastic Parts	O	O	O	O	X	X
Power Supply	X	X	X	O	X	X
Power Cord	X	O	X	O	X	X
Protective Case (if present)	O	O	O	O	X	X
Cable Assemblies (if present)	X	O	X	O	X	X
Fans (if present)	X	O	X	O	X	X
AC Filter/Fuse Assy (if present)	X	O	X	O	O	O
Ext Power Supply (if present)	X	X	X	O	X	X
Probes (if present)	X	O	X	O	X	X
O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement specified in SJ/T11363-2006.						
X: Indicates that this toxic or hazardous substance contained in at least one of the homogenous materials used for this part is above the limit requirement specified in SJ/T11363-2006.						

EFUP (Environmental Friendly Use Period) Use Conditions: refer to the environmental conditions stated in the specifications section of this Manual.

Appendix D

How to Contact Teledyne LeCroy

Type of Service	Contact
Call for technical support	US and Canada: 1 (800) 909-7112 Worldwide: 1 (408) 653-1260
Fax your questions	Worldwide: 1 (408) 727-6622
Write a letter	Teledyne LeCroy Protocol Solutions Group Customer Support 3385 Scott Blvd. Santa Clara, CA 95054-3115 USA
Send e-mail	psgsupport@teledynelecroy.com
Visit Teledyne LeCroy's web site	teledynelecroy.com/
Tell Teledyne LeCroy	Report a problem to Teledyne LeCroy Support via e-mail by selecting Help>Tell Teledyne LeCroy from the application toolbar. This requires that an e-mail client be installed and configured on the host machine.

Index

Symbols

.peg files 69

A

address 119

application 23

Auto Run 23

automatic generation 33

B

blue highlight 71

brown highlight 71

C

CATC Technical Support 119

collapse 71

Command Properties window 69, 72

components 2

configuring

Exerciser 33

contact 119

Context menu 71

creating

script 41, 43

Ctrl+N command 68

Current script position field 67

D

Direction 41

Do not export hidden packets 41

Do not export Idle packets 42

DVD-ROM 23

E

Edit as Text command 69

editing

script 71

electrical idle 34

e-mail 119

Email CATC Support 119

Enable Outlining 75

Error Log 69, 74

Errors 74

Ethernet Port 10

Ethernet port 3, 5, 8, 9, 12

executing 67

Exerciser 7

configuring 33

expand 71

Export Wait for ACK from upstream 42

Export Wait for Cpl from upstream 42

exporting

Trace to a Traffic Generation File 41

F

fax number 119

features 3, 4

File Export dialog box 41

File Tabs 74

File tabs 69

From 41

G

General page 66

generating 33, 67

theory 33

Generation Options command 43, 66

Generation Options dialog box 43, 44, 66

Go to Script Editor 72

H

host machine requirements 7

I

idle 34

Include files 43

Include statements 74

Install component selection 23

Installation DVD-ROM 2

Intellisense 71

interface 23

L

Layout 69

LeCroy PCIe Protocol Suite command 23

Link Connect toolbar button 34

Link Training sequence 33

Linkup.peg file 66

List values 71

log 74

M

Microsoft® Windows®-based host machine 23

N

New PETrainer Script 68

O

opening

program 24

outlining 71

P

packing list 2

PCI Express 16-lane advanced verification system 2

PCIe Protocol Suite

setting up 25

PCIe Protocol Suite EML

opening 24

PCIe Protocol Suite ML

opening 24

Position Trace view on packet x 72

power on/off switch 10

power socket 10

program

opening 24

progress 40

R

rear panel 10

Resume Generation button 67

S

Save all included files 43

saving

script 42

script 67

creating 41, 43

editing 71

executing 40

running 66

saving 42

Script Edit Window 71

Script Edit window 69

Script Editor 40, 69

toolbar 70

tooltips 71

Script Editor button 69

Script Editor toolbar 69

scripts 33

selecting components for installation 23

servicemarks ii

Setup command 23

Show Line Numbers 75

Show Tooltips 75

software

installation 23

Start generation button 40

Start menu 23

Start Traffic Generation button 67

Stop Generation button 67

Summit Z3-16 7

Summit Z3-16 Exerciser

to DUT 30

support 119

T

Technical Support 119

Teledyne Lecroy PCIe Protocol Suite Main Menu 24

telephone number 119

testing 33

theory 33

To 41

To Analyzer connector 13

to Generator File Format 41

Toggle Outlining 75

Trace Viewer 24

trademarks ii

traffic

generating 33, 67

traffic generation files 41, 69

traffic generation prep 66

U

unpacking 2

USB Type B Host Computer Connector 10

User input 40

V

View Options 70

View Options button 74

Viewer 24

W

Wait commands 40

Warnings 74

web site 119

Website, CATC 119